

Neck Bushing ⌀12,7-7,39/.2909

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-7,39/.2909
- Manufacturer: TRIEBEL
- Product no.: EU2017670
- Mfr. No.: 3000240V-07.39
- Diameter mm: 12,7 / 7,39
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-07.39

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instructions](#)

Neck Bushing Safety Instructions

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precise neck sizing in reloading applications. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always use the Neck Bushing in accordance with the manufacturer's instructions.
- Ensure that all safety measures outlined in this guide are followed.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of damage or wear before use.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses and gloves, when using the Neck Bushing.
- **Work Area:** Ensure your work area is clean, welllit, and free from any distractions.
- **Tool Compatibility:** Use the Neck Bushing only with compatible reloading dies from Triebel Waffenwerkzeuge.
- **Handling:** Handle the Neck Bushing carefully to avoid injury. Do not apply excessive force when inserting or removing the bushing.
- **Temperature Awareness:** Be cautious of hot surfaces if the bushing has been used in hightemperature conditions.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your reloading press is securely mounted and in good working condition.
- Gather all necessary tools and materials before starting.

2. Installation:

- Remove the existing bushing from the reloading die if applicable.
- Insert the Neck Bushing into the die, ensuring it is seated properly.
- Tighten the die according to the manufacturer's specifications, ensuring the bushing is secure.

3. Usage:

- Adjust the reloading press to the desired settings for neck sizing.
- Carefully feed the cartridge case into the reloading die with the Neck Bushing installed.
- Operate the press smoothly, applying consistent pressure to avoid damaging the bushing or the cartridge case.
- After use, remove the bushing and clean it to maintain its precision and performance.

4. PostUse:

- Store the Neck Bushing in a safe and dry location to prevent damage.
- Regularly check for wear and replace the bushing as necessary.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations regarding metal waste.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety or performance of the Neck Bushing, please contact the manufacturer or your local distributor. It is important to have access to support for safe usage and to address any concerns.

Thank you for following these safety instructions. Your attention to safety ensures a better experience with the Neck Bushing and promotes safe practices in reloading.