

Neck Bushing ⌀12,7-7,71/.3035

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-7,71/.3035
- Manufacturer: TRIEBEL
- Product no.: EU2017687
- Mfr. No.: 3000240V-07.71
- Diameter mm: 12,7 / 7,71
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-07.71

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read all instructions carefully before use.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose: precise neck sizing in reloading applications.
- Always handle the Neck Bushing with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of wear or damage before use.
- If you notice any defects or irregularities, discontinue use immediately and seek guidance.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Neck Bushing.
- Ensure that the reloading die and the Neck Bushing are compatible and correctly fitted.
- Do not exceed the recommended sizing limits specified for the Neck Bushing.
- Avoid using excessive force during the sizing process to prevent damage to the bushing or the reloading die.
- Do not modify or attempt to repair the Neck Bushing. Any alterations may compromise safety and performance.

Instructions for Installation and Usage

1. Preparation:

- Clean the Neck Bushing and the reloading die to remove any debris or contaminants.
- Ensure that your workspace is clean, organized, and free from hazards.

2. Installation:

- Insert the Neck Bushing into the reloading die according to the manufacturer's instructions.
- Ensure that the bushing is seated properly and securely within the die.

3. Usage:

- Adjust your reloading press to the appropriate settings for neck sizing.
- Place the case in the reloading press and engage the press to begin the sizing process.
- Monitor the operation closely, ensuring that the Neck Bushing is functioning correctly throughout the process.
- After sizing, remove the case and inspect it for any signs of damage or improper sizing.

4. PostUsage:

- Clean the Neck Bushing after each use to maintain its performance and longevity.
- Store the Neck Bushing in a safe and dry location, away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations.
- If the product is damaged or no longer usable, consider recycling the material where possible to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Neck Bushing, please refer to the contact information provided by the manufacturer or retailer from whom you purchased the product.