

Neck Bushing ⌀12,7-7,98/.3142

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-7,98/.3142
- Manufacturer: TRIEBEL
- Product no.: EU2017701
- Mfr. No.: 3000240V-07.98
- Diameter mm: 12,7 / 7,98
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-07.98

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for purchasing the Neck Bushing. This guide provides important safety instructions and usage information to ensure your safe and effective use of the product. Please read this guide carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose of neck sizing in reloading applications.
- Always inspect the Neck Bushing for any signs of damage or wear before each use.
- Keep the Neck Bushing out of reach of children and vulnerable individuals to prevent accidental injury.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling and using the Neck Bushing.
- Follow all manufacturer instructions for the reloading process to avoid accidents and ensure safety.

Specific Safety Precautions for Use

- Only use the Neck Bushing with compatible reloading dies from Triebel Waffenwerkzeuge.
- Do not exceed the recommended dimensions and specifications when using the Neck Bushing.
- Avoid using excessive force during the neck sizing process to prevent damage to the bushing or injury.
- Ensure that your workspace is clean and organized to minimize the risk of accidents.
- Be aware of your surroundings and avoid distractions while using the Neck Bushing.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials, including the Neck Bushing, reloading die, and reloading press.
- Ensure that your reloading workstation is clean and welllit.

2. Installation:

- Remove the reloading die from your press.
- Carefully insert the Neck Bushing into the reloading die, ensuring it is properly seated.
- Reinstall the die into the press, tightening it securely.

3. Usage:

- Prepare your brass cases by cleaning and inspecting them for damage.
- Insert a brass case into the press and lower the ram to engage the Neck Bushing.
- Apply steady pressure to resize the neck of the case, ensuring not to apply excessive force.
- Once resized, remove the brass case and inspect it for proper sizing.

4. Postusage:

- Clean the Neck Bushing after each use to remove any debris or residue.
- Store the Neck Bushing in a safe and dry location when not in use.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations.
- Do not dispose of the Neck Bushing in regular household waste if it is damaged or worn.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries or further assistance, please refer to the manufacturer's contact information provided with your purchase. It is important to reach out for support if you have any questions regarding the use or safety of the Neck Bushing.

By following these safety instructions, you can ensure a safe and effective experience with your Neck Bushing. Always prioritize safety and adhere to the guidelines provided. Thank you for choosing our product!