

Neck Bushing ⌀12,7-8,33/.3280

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Neck Bushing ⌀12,7-8,33/.3280](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017714
- Mfr. No.: 3000240V-08.33
- Diameter mm: 12,7 / 8,33
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.33

Table of Contents

- [Startpage](#)
- [Neck Bushing Safety Instruction Guide](#)
- [About Us](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides important safety information and instructions to ensure the safe and effective use of the product. Please read this guide carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose, which is precise neck sizing in reloading applications.
- Always inspect the Neck Bushing for any signs of damage or wear before use.
- Keep the Neck Bushing out of reach of children and vulnerable individuals to prevent accidents.
- Use the Neck Bushing only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Follow all safety precautions and guidelines provided in this manual and any additional documentation.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses, when using the Neck Bushing to protect against debris and potential injuries.
- Do not exceed the specified dimensions or tolerances when using the Neck Bushing to avoid malfunction or damage.
- Ensure that the work area is clean, dry, and free of any obstructions before starting the reloading process.
- Avoid using the Neck Bushing if you are tired, distracted, or under the influence of substances that may impair your judgment.
- Never attempt to modify or alter the Neck Bushing in any way, as this may compromise its safety and effectiveness.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials before starting the installation.
- Ensure that your reloading press is clean and properly set up.

2. Installation

- Remove the current bushing from your reloading die, if applicable.
- Carefully insert the Neck Bushing into the die, ensuring it is seated securely.
- Tighten any locking mechanisms or screws as per the manufacturer's instructions.

3. Usage

- Adjust the reloading press settings according to the specifications for the caliber you are working with.
- Place the cartridge case into the reloading press and engage the Neck Bushing gently.
- Apply consistent pressure to resize the neck of the cartridge case, ensuring even results.
- Inspect each resized case for quality and consistency before proceeding to the next step in the reloading process.

4. PostUsage Care

- After use, clean the Neck Bushing to remove any debris or residue.

- Store the Neck Bushing in a dry, safe place to prevent damage.

Disposal Instructions

- Dispose of the Neck Bushing responsibly at the end of its life cycle.
- Follow local regulations for the disposal of metal products.
- Do not dispose of the Neck Bushing in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer's contact details provided with your purchase.

By adhering to these safety instructions, you can ensure the safe and effective use of the Neck Bushing, contributing to a successful reloading experience. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk