

Neck Bushing ⌀12,7-8,36/.3291

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,36/.3291
- Manufacturer: TRIEBEL
- Product no.: EU2017716
- Mfr. No.: 3000240V-08.36
- Diameter mm: 12,7 / 8,36
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.36

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for purchasing the Neck Bushing. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read this document carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose: precise neck sizing in reloading processes.
- Always inspect the Neck Bushing for any signs of damage or wear before use. Do not use a damaged bushing.
- Keep the Neck Bushing out of reach of children and vulnerable individuals to prevent accidental injury.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling and using the Neck Bushing.
- Follow all local regulations and guidelines regarding the handling and use of reloading equipment.

Specific Safety Precautions for Use

- Always ensure that the reloading die is securely mounted before inserting the Neck Bushing.
- When adjusting or changing the Neck Bushing, make sure the reloading press is not in operation.
- Avoid wearing loose clothing or jewelry that could become caught in the reloading equipment while in use.
- Ensure that your work area is clean and free from obstructions to prevent accidents.
- Do not attempt to modify or alter the Neck Bushing in any way, as this can compromise safety and performance.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and disconnected from any power source.
- Remove the existing bushing from the reloading die, if applicable.
- Insert the Neck Bushing into the reloading die, ensuring a snug fit.
- Secure the bushing by tightening the locking mechanism as per the manufacturer's instructions.

2. Usage:

- Prepare the brass cases according to your reloading specifications.
- Insert the brass case into the reloading die equipped with the Neck Bushing.
- Operate the reloading press slowly and steadily, ensuring that the neck sizing process is performed evenly.
- After use, remove the brass case and inspect it for proper sizing.
- Clean the Neck Bushing after each use to maintain its performance and longevity.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local waste management regulations.
- If the Neck Bushing is damaged or no longer functional, do not attempt to repair it. Instead, dispose of it responsibly.
- Recycle materials whenever possible to reduce environmental impact.

Contact Information for Further Support

For any inquiries or concerns regarding the Neck Bushing, please refer to the contact information provided on the packaging or product documentation. It is important to have access to support for any safetyrelated questions.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the Neck Bushing effectively and safely.