

Neck Bushing ⌀12,7-8,41/.3311

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,41/.3311
- Manufacturer: TRIEBEL
- Product no.: EU2017720
- Mfr. No.: 3000240V-08.41
- Diameter mm: 12,7 / 8,41
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.41

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instructions](#)

Neck Bushing Safety Instructions

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety information and instructions to ensure the safe and effective use of the product. Please read this guide carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose, which is precise neck sizing in reloading applications.
- Always inspect the Neck Bushing for any signs of damage or wear before use. Do not use a damaged product.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Use protective eyewear and gloves when handling the Neck Bushing to prevent injury.
- Store the Neck Bushing in a safe and dry place when not in use.

Specific Safety Precautions for Use

- Do not exceed the recommended sizing specifications for the Neck Bushing.
- Avoid using excessive force during the neck sizing process, as this may lead to equipment failure or personal injury.
- Ensure that the reloading die and the Neck Bushing are compatible to avoid malfunctions.
- Follow all manufacturer instructions for the reloading equipment used in conjunction with the Neck Bushing.
- If you experience any unusual resistance or difficulty while using the Neck Bushing, stop immediately and inspect for possible issues.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials, including the reloading die, press, and the Neck Bushing.
- Ensure your workspace is clean and organized.

2. Installation:

- Remove the reloading die from the press if it is already installed.
- Insert the Neck Bushing into the reloading die according to the manufacturer's instructions.
- Secure the reloading die back into the press.

3. Usage:

- Place the cartridge case into the reloading press.
- Operate the press slowly and steadily, ensuring that the Neck Bushing engages with the cartridge case properly.
- Monitor the process closely for any signs of difficulty or unusual resistance.

4. PostUse:

- After use, remove the Neck Bushing from the reloading die.
- Clean the Neck Bushing and store it in a safe location.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations.
- If the Neck Bushing is damaged or no longer usable, consider recycling options if available.
- Do not dispose of the Neck Bushing in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Neck Bushing, please contact the manufacturer or authorized distributor. Ensure that you have the product information ready for reference.

By following these instructions and safety guidelines, you can ensure a safe and effective experience with your Neck Bushing. Thank you for your attention to safety.