

Neck Bushing ⌀12,7-8,42/.3315

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,42/.3315
- Manufacturer: TRIEBEL
- Product no.: EU2017721
- Mfr. No.: 3000240V-08.42
- Diameter mm: 12,7 / 8,42
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.42

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for choosing the Neck Bushing, designed for precise neck sizing in reloading applications. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this document carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure the Neck Bushing is compatible with your reloading die setup.
- Always inspect the Neck Bushing for any signs of damage or wear before use.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Use the Neck Bushing only for its intended purpose as specified in this guide.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when handling the Neck Bushing.
- Do not exceed the recommended sizing limits specified for the Neck Bushing.
- Ensure that the reloading press is securely mounted and stable before use.
- Avoid using excessive force when sizing to prevent damage to the bushing or reloading equipment.
- Do not attempt to modify or alter the Neck Bushing in any way.
- If the bushing becomes stuck, do not force it; instead, seek assistance.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting.
- Ensure your reloading press is clean and free of debris.

2. Installation:

- Insert the Neck Bushing into the reloading die according to the manufacturer's instructions.
- Secure the bushing in place to ensure it does not move during operation.

3. Usage:

- Place the cartridge case in the reloading press.
- Slowly and evenly apply pressure to the handle to size the neck of the cartridge.
- Monitor the process to ensure that the sizing is consistent and within specifications.
- Remove the sized case and inspect it for proper dimensions.

4. PostUsage:

- Clean the Neck Bushing after each use to prevent buildup of debris.
- Store the Neck Bushing in a dry, safe place away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations.

- If the product is damaged beyond use, ensure that it is recycled or disposed of responsibly to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's website or customer service resources.

Thank you for prioritizing safety while using the Neck Bushing. Your careful attention to these instructions helps ensure a safe and effective reloading experience.