

Neck Bushing ⌀12,7-8,44/.3323

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,44/.3323
- Manufacturer: TRIEBEL
- Product no.: EU2017723
- Mfr. No.: 3000240V-08.44
- Diameter mm: 12,7 / 8,44
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.44

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precision neck sizing and is made from highquality hardened steel. To ensure your safety and the effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the Neck Bushing as intended to avoid accidents or malfunctions.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Inspect the Neck Bushing before each use for any signs of damage or wear.
- Do not use the Neck Bushing if it appears damaged or compromised in any way.
- Follow all instructions for proper handling and storage to maintain the integrity of the product.
- In case of any safety concerns, report unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the Neck Bushing is compatible with your reloading dies before use.
- Wear appropriate personal protective equipment (PPE), such as safety goggles and gloves, when handling the Neck Bushing.
- Use the Neck Bushing in a wellventilated area to avoid inhalation of any particles generated during use.
- Avoid excessive force when using the Neck Bushing to prevent injury or damage to the product.
- Always follow the manufacturer's guidelines for operation and maintenance.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials needed for the reloading process.
- Ensure your workspace is clean and organized.

2. Installation of the Neck Bushing

- Remove the reloading die from your press.
- Insert the Neck Bushing into the die, ensuring it fits securely.
- Reattach the die to the press, making sure it is properly aligned.

3. Usage of the Neck Bushing

- Adjust the die according to your desired neck sizing specifications.
- Place the cartridge case into the press and operate it according to your reloading procedure.
- Check the neck sizing after each operation for consistency and accuracy.

4. PostUsage Care

- Clean the Neck Bushing after each use to remove any debris or residues.
- Store the Neck Bushing in a safe, dry place to prevent rust or damage.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations for metal waste.
- Do not dispose of the Neck Bushing in regular household waste.

- If you are unsure of how to dispose of the product, contact your local waste management authority for guidance.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please refer to the manufacturer's contact information provided with the product packaging or on the official website.

Thank you for following these safety instructions. Your adherence to these guidelines will help ensure a safe and effective reloading experience.