

Neck Bushing ⌀12,7-8,45/.3327

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,45/.3327
- Manufacturer: TRIEBEL
- Product no.: EU2017724
- Mfr. No.: 3000240V-08.45
- Diameter mm: 12,7 / 8,45
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.45

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for choosing the Neck Bushing. This guide provides important safety instructions to ensure the safe and effective use of the product. Please read this guide carefully before using the Neck Bushing to minimize any risks associated with its use.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose—precise neck sizing in reloading applications.
- Always follow the manufacturer's instructions when using the Neck Bushing.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the Neck Bushing for any signs of damage or wear before each use. Do not use if damaged.
- Report any unsafe conditions or accidents involving the Neck Bushing to the relevant authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment, including safety glasses and gloves, while using the Neck Bushing.
- Ensure that the work area is welllit and free from clutter to prevent accidents.
- Do not exceed the specified diameter limits of the Neck Bushing (12.7 mm / 8.45 mm).
- Use the Neck Bushing only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Avoid using excessive force when sizing to prevent damage to the bushing or the reloading die.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged before installation.
- Remove any existing bushing from the reloading die.
- Carefully insert the Neck Bushing into the die, ensuring it is seated properly.
- Secure the bushing according to the die manufacturer's instructions.

2. Usage:

- Prepare your brass cases according to standard reloading practices.
- Insert the brass case into the reloading die with the Neck Bushing installed.
- Operate the reloading press slowly and steadily to size the neck of the brass case.
- After sizing, inspect the case to ensure it meets the desired specifications.
- Clean the Neck Bushing after use to maintain its performance and longevity.

Disposal Instructions

- Dispose of the Neck Bushing responsibly. Do not throw it in regular household waste.
- Check local regulations for proper disposal methods for metal components.
- If the Neck Bushing is no longer usable, consider recycling it if possible.

Contact Information for Further Support

For any inquiries regarding the Neck Bushing, please refer to the manufacturer's contact information provided on the product packaging or visit the manufacturer's website for more support.

Thank you for following these safety instructions. Your safety and satisfaction are our top priority.