

Neck Bushing ⌀12,7-8,47/.3335

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,47/.3335
- Manufacturer: TRIEBEL
- Product no.: EU2017726
- Mfr. No.: 3000240V-08.47
- Diameter mm: 12,7 / 8,47
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.47

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This safety instruction guide provides essential information to ensure the safe and proper use of this product. Please read through all sections carefully before using the Neck Bushing to avoid any potential hazards.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose, which is precise neck sizing in reloading applications.
- Always handle the Neck Bushing with care to avoid injury. The edges may be sharp.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the Neck Bushing for any signs of wear or damage before use. Do not use if damaged.
- Follow all local regulations regarding the use of reloading equipment and components.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling and using the Neck Bushing.
- Ensure that the reloading press and equipment are properly set up and secured before using the Neck Bushing.
- Do not exceed the recommended specifications for the Neck Bushing. Refer to your reloading die instructions for guidance.
- Avoid using excessive force when resizing necks to prevent equipment failure or personal injury.
- If you experience any unusual resistance or difficulty while using the Neck Bushing, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and materials, including the Neck Bushing, reloading press, and appropriate dies.
- Ensure your work area is clean and welllit to reduce the risk of accidents.

2. Installation

- Remove any existing bushing from your reloading die if applicable.
- Insert the Neck Bushing into the die according to the manufacturer's instructions.
- Secure the bushing in place, ensuring it is properly aligned.

3. Usage

- Place the cartridge case into the reloading press.
- Slowly and steadily apply pressure to resize the neck of the cartridge case using the Neck Bushing.
- Monitor the process closely to ensure proper sizing and avoid excessive force.
- After resizing, inspect the cartridge case to verify that it meets your specifications.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations for metal recycling or waste disposal.
- Do not dispose of the Neck Bushing in general household waste.

- If the Neck Bushing is damaged beyond repair, ensure it is safely stored until proper disposal can be arranged.

Contact Information for Further Support

For any inquiries or additional support regarding the Neck Bushing, please refer to the manufacturer's contact information included with the product packaging or visit the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Neck Bushing. Always prioritize safety and compliance with local regulations when using reloading equipment. Thank you for your attention to these important guidelines.