

Neck Bushing ⌀12,7-8,56/.3370

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,56/.3370
- Manufacturer: TRIEBEL
- Product no.: EU2017734
- Mfr. No.: 3000240V-08.56
- Diameter mm: 12,7 / 8,56
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.56

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for choosing the Neck Bushing from TRIEBEL. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of the product. Please read this document carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose: precise neck sizing in reloading applications.
- Always inspect the Neck Bushing for any signs of damage or wear before each use. Do not use if damaged.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when working with reloading equipment.
- Follow all local regulations and guidelines related to reloading and ammunition handling.

Specific Safety Precautions for Use

- Always ensure that the reloading die is securely attached to your reloading press before using the Neck Bushing.
- Do not exceed the recommended specifications for the Neck Bushing, including diameter and compatibility with your reloading die.
- Avoid applying excessive force when resizing cases to prevent damage to the Neck Bushing and ensure consistent results.
- Maintain a clean work environment to reduce the risk of accidents and ensure safe handling of materials.
- Be aware of the potential for metal shavings or debris during use. Clean the work area regularly to avoid slips or injuries.

Instructions for Installation and Usage

Installation Instructions

1. **Preparation:** Ensure that your reloading press is clean and free of any obstructions.
2. **Attach the Neck Bushing:**
 - Remove the existing bushing from your reloading die.
 - Insert the Neck Bushing into the die, ensuring it is seated properly.
 - Secure the bushing by tightening the appropriate locking mechanism on the die.
3. **Check Alignment:** Ensure that the Neck Bushing is aligned correctly with the reloading press.

Usage Instructions

1. **Loading Cases:**
 - Insert the case into the reloading press, ensuring it is positioned correctly under the Neck Bushing.
2. **Resizing Process:**
 - Gradually apply pressure on the handle of the reloading press to resize the case.
 - Monitor the process to ensure that the Neck Bushing operates smoothly without excessive force.
3. **Inspection:**
 - After resizing, inspect the case for proper dimensions and any signs of damage.
 - Remove the resized case and prepare for the next step in the reloading process.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations regarding metal waste.
- Do not dispose of the Neck Bushing in regular household waste. Instead, use designated recycling or hazardous waste facilities.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's contact details available on the product packaging or the official website.

By following these safety instructions, you can ensure a safe and effective experience with your Neck Bushing. Always prioritize safety and compliance with local regulations when engaging in reloading activities. Thank you for your attention to these important guidelines.