

Neck Bushing ⌀12,7-8,59/.3382

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,59/.3382
- Manufacturer: TRIEBEL
- Product no.: EU2017737
- Mfr. No.: 3000240V-08.59
- Diameter mm: 12,7 / 8,59
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.59

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing, a precision tool designed for neck sizing in reloading applications. This guide provides important safety instructions and guidelines to ensure the safe and effective use of this product. Please read this guide thoroughly before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose of neck sizing in reloading processes.
- Always follow the manufacturer's instructions and recommendations for use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of damage or wear before each use.
- If you notice any defects, do not use the product and contact the manufacturer for support.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves, while using the Neck Bushing.
- Ensure that the reloading press is stable and securely positioned before beginning the neck sizing process.
- Avoid wearing loose clothing or jewelry that could get caught in the machinery during operation.
- Do not force the Neck Bushing into the reloading die; if resistance is encountered, stop and check for obstructions.
- Always keep your hands and other body parts clear of moving parts during operation.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary materials, including the Neck Bushing, reloading die, and appropriate reloading press.
- Ensure that your workspace is clean and welllit.

2. Installation

- Remove the reloading die from the press if it is already installed.
- Insert the Neck Bushing into the reloading die according to the manufacturer's instructions.
- Secure the die back into the press, ensuring that the Neck Bushing is properly seated.

3. Usage

- Place the cartridge case into the reloading die.
- Operate the reloading press according to the manufacturer's guidelines, applying steady and even pressure.
- After sizing, inspect the cartridge case for proper neck dimensions and any signs of damage.
- Clean the Neck Bushing after each use to maintain performance and longevity.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations regarding metal waste.
- If the product is damaged or no longer usable, ensure it is disposed of safely to prevent injury to others.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please contact the manufacturer directly through their official communication channels. Ensure to provide details about your product and any issues encountered.

By following these safety instructions and guidelines, you can ensure a safe and effective experience with the Neck Bushing. Always prioritize safety and proper usage to maximize the performance of your reloading equipment. Thank you for your attention to these important safety measures.