

Neck Bushing ⌀12,7-8,60/.3386

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,60/.3386
- Manufacturer: TRIEBEL
- Product no.: EU2017738
- Mfr. No.: 3000240V-08.60
- Diameter mm: 12,7 / 8,60
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.60

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing for your reloading needs. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read all sections carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose: precise neck sizing in reloading applications.
- Always follow the manufacturer's instructions when using the Neck Bushing in conjunction with reloading dies.
- Keep the Neck Bushing out of reach of children and vulnerable individuals to prevent accidental injury.
- Regularly inspect the Neck Bushing for signs of wear or damage. Do not use if damaged.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses, when using the Neck Bushing.
- Ensure that the reloading setup is stable and secure before beginning the sizing process.
- Do not exceed the specified dimensions or tolerances for the Neck Bushing to prevent malfunction or accidents.
- Avoid using excessive force during operation; this may lead to equipment failure or personal injury.
- If you experience any unusual resistance or difficulty while using the Neck Bushing, stop immediately and inspect the setup.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is compatible with the Neck Bushing.
- Carefully insert the Neck Bushing into the designated die according to the manufacturer's instructions.
- Secure the Neck Bushing firmly to prevent any movement during operation.

2. Usage

- Prepare the cases to be resized according to standard reloading practices.
- Place the case in the reloading press and engage the Neck Bushing gently.
- Apply consistent pressure to resize the neck of the case without excessive force.
- After resizing, remove the case and inspect it for proper dimensions and any signs of damage.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations regarding metal waste.
- Do not dispose of the Neck Bushing in regular household waste. Check with local recycling facilities for proper disposal methods.

Contact Information for Further Support

For further assistance or inquiries regarding safety, please refer to the manufacturer's contact information provided with the product packaging.