

Neck Bushing ⌀12,7-8,68/.3417

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-8,68/.3417
- Manufacturer: TRIEBEL
- Product no.: EU2017740
- Mfr. No.: 3000240V-08.68
- Diameter mm: 12,7 / 8,68
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-08.68

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing, a precision tool designed for neck sizing in reloading applications. This guide provides important safety instructions and guidelines to ensure safe and effective use of the product. Please read this guide carefully before using the Neck Bushing.

General Safety Guidelines

- Always use the Neck Bushing in accordance with the manufacturer's instructions and guidelines.
- Ensure that the workspace is clean and free from any hazards that could cause accidents.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of wear or damage before each use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves while handling the Neck Bushing.
- Only use the Neck Bushing with compatible reloading dies from Triebel Waffenwerkzeuge.
- Avoid using excessive force when sizing necks; this may lead to tool damage or personal injury.
- Do not modify the Neck Bushing in any way, as this may compromise its safety and performance.
- Ensure proper alignment of the Neck Bushing during use to avoid misfires or accidents.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure your reloading press is clean and in good working condition.
2. **Insert the Neck Bushing:**
 - Carefully remove the existing bushing from the reloading die.
 - Insert the Neck Bushing into the die, ensuring it is seated properly.
3. **Secure the Die:**
 - Tighten the locking ring of the die to secure the Neck Bushing in place.
 - Doublecheck that the bushing is firmly in position.

Usage

1. **Setting Up:**
 - Adjust the reloading press according to your specifications for neck sizing.
 - Ensure that the Neck Bushing is aligned correctly with the cartridge case.
2. **Sizing Process:**
 - Place the cartridge case into the die.
 - Operate the press smoothly and steadily to size the neck of the cartridge.
3. **Inspection:**
 - After sizing, inspect the cartridge neck for uniformity and dimensions.
 - If any issues are detected, discontinue use and inspect the Neck Bushing for damage.

Disposal Instructions

- Dispose of the Neck Bushing responsibly. Do not dispose of it in regular household waste.
- Check local regulations for proper disposal methods for metal and tools.
- If the Neck Bushing is damaged or unusable, consider recycling it where possible.

Contact Information for Further Support

For any inquiries related to safety, usage, or product support, please refer to the manufacturer's contact information provided with your product. Ensure you have your product details ready when seeking assistance.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities. Enjoy using your Neck Bushing responsibly!