

Neck Bushing ⌀15-9,08/.3575

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀15-9,08/.3575
- Manufacturer: TRIEBEL
- Product no.: EU2017760
- Mfr. No.: 3000241V-09.08
- Diameter mm: 15 / 9,08
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000241V-09.08

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides important safety information and instructions for the proper use, installation, and disposal of your product. Please read this guide carefully to ensure safe and effective use.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose of neck sizing in reloading processes.
- Always use the product in a wellventilated area to avoid inhalation of any dust or debris generated during use.
- Keep the Neck Bushing out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the Neck Bushing for any signs of wear or damage before use. Do not use if damaged.
- Follow all manufacturer guidelines and recommendations for use to ensure safety and effectiveness.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), including safety goggles and gloves, when handling or using the Neck Bushing.
- Avoid direct contact with sharp edges of the bushing to prevent cuts or injuries.
- Ensure that the reloading equipment is properly set up and secure before using the Neck Bushing.
- Do not exceed the recommended pressure limits when using the Neck Bushing to avoid breakage or malfunction.
- Always follow the reloading die manufacturer's instructions for compatibility and safe operation.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Carefully remove the existing bushing from the die, if applicable.
- Insert the Neck Bushing into the die, ensuring it fits snugly and securely.
- Tighten any locking mechanisms to ensure the bushing is held firmly in place.

2. Usage:

- Set up your reloading press according to the manufacturer's instructions.
- Place the case to be resized into the reloading die with the installed Neck Bushing.
- Apply even pressure to the handle of the reloading press to resize the neck of the case.
- Check the resized case for proper dimensions and concentricity before proceeding with further reloading steps.
- Clean the Neck Bushing after use to maintain its performance and longevity.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations for metal waste.
- Do not dispose of the product in regular household waste.
- If the Neck Bushing is damaged or no longer usable, consider recycling it at a designated facility.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please reach out to the manufacturer or authorized distributor. Ensure you have the product details at hand for efficient assistance.

Thank you for your attention to these safety instructions. By following these guidelines, you help ensure a safe and effective reloading experience.