

Neck Bushing ⌀15-10,86/.4276

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀15-10,86/.4276
- Manufacturer: TRIEBEL
- Product no.: EU2017812
- Mfr. No.: 3000241V-10.86
- Diameter mm: 15 / 10,86
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000241V-10.86

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for purchasing the Neck Bushing. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of the product. Please read this guide thoroughly before using the Neck Bushing to avoid any hazards and ensure a safe experience.

General Safety Guidelines

- Always use the Neck Bushing in accordance with the manufacturer's instructions.
- Ensure that the work area is clean and free from any obstructions before using the product.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of wear or damage before use. Do not use if damaged.
- Store the Neck Bushing in a safe and dry location when not in use to prevent rust and damage.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while using the Neck Bushing.
- Ensure that the Neck Bushing is compatible with your reloading die and equipment before use.
- Avoid exceeding the recommended specifications for neck sizing to prevent injury or damage.
- Do not force the Neck Bushing into the reloading die; ensure a proper fit before proceeding.
- Be aware of your surroundings while using the Neck Bushing to avoid accidents.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for your reloading process.
- Ensure that your reloading press is clean and properly set up.

2. Installation of the Neck Bushing:

- Remove any existing bushing from your reloading die.
- Carefully insert the Neck Bushing into the die, ensuring it is seated properly.
- Tighten the die according to the manufacturer's specifications.

3. Using the Neck Bushing:

- Place the cartridge case into the shell holder of your reloading press.
- Operate the press according to the manufacturer's instructions, applying steady pressure to size the neck of the cartridge case.
- Inspect the sized neck for proper dimensions and concentricity.

4. PostUse:

- After use, carefully remove the Neck Bushing from the die.
- Clean the Neck Bushing with a soft cloth to remove any residue.
- Store the Neck Bushing in a safe location.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations for metal products.

- Do not throw the Neck Bushing in regular household waste to prevent environmental harm.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Neck Bushing, please refer to the manufacturer's contact information provided with your product.

By following these guidelines, you can ensure a safe and effective experience with your Neck Bushing. Thank you for your attention to safety.