

Hold Down Die & Swage Setter - Indexing Arm Spring for Dillon XL650 - 13965

[Rifle Parts](#) > [Receiver Parts](#) > [Receiver Hardware](#) > [Springs](#)

Keep your Dillon Precision press cycling with the exact reliability you expect. This high-grade replacement component is precision-crafted to match original equipment specifications, delivering a flawless fit and uninterrupted functionality for your high-volume reloading needs.



Attributes

- Name: [Indexing Arm Spring for Dillon XL650 - 13965](#)
- Manufacturer: [ARMANOV](#)
- Product no.: EU2018366
- Mfr. No.: INDARMSPR650
- Colour: Silver
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Hold Down Die & Swage Setter Indexing Arm Spring for Dillon XL650](#)
- [About Us](#)

Safety Instruction Guide for Hold Down Die & Swage Setter Indexing Arm Spring for Dillon XL650

Introduction

Thank you for choosing the Hold Down Die & Swage Setter Indexing Arm Spring for your Dillon XL650 reloading press. This guide provides essential safety instructions and precautions to ensure safe and effective use of this product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure the product is used for its intended purpose only.
- Always follow the manufacturer's instructions for installation and use.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for any signs of wear or damage.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use only with Dillon XL650 reloading presses.
- Do not modify the product in any way as it may compromise safety and functionality.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the product.
- Ensure the press is powered off and disconnected from any power source during installation or maintenance.
- Avoid placing hands near moving parts during operation to prevent injury.
- Do not exceed the recommended load limits for the reloading press.

Instructions for Installation and Usage

1. Installation

- Ensure that the Dillon XL650 press is powered off and unplugged.
- Remove the existing indexing arm spring by following the manufacturer's instructions.
- Carefully install the new Hold Down Die & Swage Setter Indexing Arm Spring, ensuring it is positioned correctly.
- Doublecheck that all components are securely attached and in proper working order.

2. Usage

- Power on the Dillon XL650 press and conduct a test cycle without any materials to ensure proper function.
- Monitor the operation of the spring during use. If any unusual sounds or movements occur, stop using the press immediately and inspect for issues.
- Maintain a clean and organized workspace to prevent accidents.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.

- Consider recycling options where available to minimize environmental impact.

Contact Information for Further Support

For any inquiries or concerns regarding the product, please refer to the manufacturer's contact information provided on the packaging or the official website.

By following these guidelines, you can ensure a safe and effective experience with your Hold Down Die & Swage Setter Indexing Arm Spring for Dillon XL650. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk