

Hold Down Die & Swage Setter - Index Ball Spring for Dillon Presses - 13997

Safeguard the precision and smooth operation of your Dillon Precision setup. This premium replacement part is built to mirror original tolerances down to the millimeter, ensuring a seamless, worry-free installation and the long-term reliability your reloading bench deserves.



Attributes

- Name: Index Ball Spring for Dillon Presses - 13997
- Manufacturer: ARMANOV
- Product no.: EU2018367
- Mfr. No.: INDBALSPR
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Hold Down Die & Swage Setter Index Ball Spring for Dillon Presses 13997](#)

Safety Instruction Guide for Hold Down Die & Swage Setter Index Ball Spring for Dillon Presses 13997

Introduction

Thank you for choosing the Hold Down Die & Swage Setter Index Ball Spring for Dillon Presses. This premium replacement part is designed to ensure the precision and smooth operation of your Dillon Precision setup. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is compatible with your specific Dillon Press model.
- Always handle the product with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all manufacturer instructions for safe operation of your Dillon Press.

Specific Safety Precautions for Use

- Use only in accordance with Dillon Precision equipment specifications.
- Do not modify the product in any way, as this may compromise safety and performance.
- Avoid using the product in wet or damp conditions to prevent slip hazards.
- If you experience any unusual noises or performance issues during use, stop immediately and inspect the product.
- Wear appropriate personal protective equipment (PPE) such as safety glasses when operating the Dillon Press.

Instructions for Installation and Usage

1. Preparation

- Ensure the Dillon Press is powered off and unplugged before installation.
- Gather all necessary tools for installation.

2. Installation Steps

- Remove the existing index ball spring from the Dillon Press.
- Clean the area where the new index ball spring will be installed.
- Carefully insert the new Hold Down Die & Swage Setter Index Ball Spring into the designated slot.
- Ensure that the spring is seated properly and securely.

3. Usage

- Once installed, reconnect and power on the Dillon Press.
- Test the operation of the press to ensure the new spring is functioning correctly.
- Follow the Dillon Press operating instructions for safe and effective use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any inquiries or safety concerns regarding this product, please contact the manufacturer or your local distributor. Ensure that you have the product details and any relevant information ready for assistance.

Thank you for prioritizing safety and performance with your Dillon Precision equipment.