

RUGER 1022 Competition Trigger Complete Assembly - RUGER 1022, GOLD SHOE-COMPETITION ****3lb****

Match-Compliant Pull Weight: Factory preset to a crisp 3 lbs. to strictly adhere to organized rimfire match rules while providing maximum shot-to-shot consistency.



Integrated Extended Mag Release: Features Timney's single-finger release lever, allowing for lightning-fast, seamless magazine changes during timed stages.

True Drop-In Installation: Precision-engineered as a complete, self-contained module. Easily swaps with your factory trigger housing in minutes—no gunsmithing needed.

Custom Aesthetics: Customize your setup with your choice of a Black or Silver housing, paired with 6 vibrant trigger shoe color options (Black, Red, Blue, Gold, Green, or Silver).

Uncompromising USA Craftsmanship: Precision-machined from premium materials in Phoenix, Arizona, and backed by Timney's legendary No-Hassle Lifetime Warranty.

Attributes

- Name: RUGER 1022, GOLD SHOE-COMPETITION ****3lb****
- Manufacturer: TIMNEY
- Product no.: EU2018780
- Mfr. No.: 1022-4C-COMP
- Colour: Gold
- Model: 10/22
- Weapon type: Ruger
- Delivery weight: 0.09kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950242863

Table of Contents

- [Startpage](#)
- [English: RUGER 1022 Competition Trigger Complete Assembly Safety Instructions](#)

RUGER 1022 Competition Trigger Complete Assembly Safety Instructions

Introduction

Thank you for choosing the RUGER 1022 Competition Trigger Complete Assembly. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this manual carefully before installation and usage.

General Safety Guidelines

- Ensure that the product is used in accordance with all local laws and regulations regarding firearms and modifications.
- Always treat firearms as if they are loaded. Keep the muzzle pointed in a safe direction at all times.
- Store the trigger assembly in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the trigger assembly for signs of wear or damage. If any issues are found, discontinue use immediately and seek assistance.
- Do not modify the trigger assembly beyond the manufacturer's specifications.

Specific Safety Precautions for Use

- The RUGER 1022 Competition Trigger is designed for use with the RUGER 10/22 model only. Do not attempt to use it with any other firearm.
- Ensure that the firearm is unloaded before installing or handling the trigger assembly.
- Use proper safety gear, including eye and ear protection, when testing or using the firearm.
- Follow all safety protocols for handling firearms, including keeping your finger off the trigger until ready to shoot.
- Be aware of your surroundings and ensure a safe backdrop when firing.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure the firearm is unloaded and in a safe condition before beginning installation.
2. **Remove the Factory Trigger:**
 - Disassemble the firearm according to the manufacturer's instructions.
 - Remove the factory trigger housing by following the disassembly steps in the RUGER 10/22 manual.
3. **Install the Competition Trigger:**
 - Carefully place the RUGER 1022 Competition Trigger Complete Assembly into the trigger housing.
 - Ensure that all components are securely in place and properly aligned.
4. **Reassemble the Firearm:**
 - Follow the reassembly steps in the RUGER 10/22 manual to reassemble the firearm with the new trigger assembly.
5. **Test the Trigger:**
 - Once reassembled, conduct a function check to ensure that the trigger operates correctly.
 - Ensure that the trigger pull weight is at the factory preset of 3 lbs.

Usage

- After installation, familiarize yourself with the new trigger pull weight and feel before using the firearm in a live environment.
- Always follow the safety guidelines outlined above during use.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the trigger assembly is no longer in use, ensure it is stored safely or disposed of in a secure manner to prevent unauthorized access.

Contact Information for Further Support

For additional assistance or inquiries regarding the RUGER 1022 Competition Trigger Complete Assembly, please refer to the manufacturer's website or contact your local dealer.

By adhering to these safety instructions, you can ensure a safe and enjoyable experience with your RUGER 1022 Competition Trigger Complete Assembly. Thank you for your commitment to safety.