

RUGER 1022 Competition Trigger Complete Assembly - RUGER 1022, GREEN SHOE-COMPETITION **3lb**

Match-Compliant Pull Weight: Factory preset to a crisp 3 lbs. to strictly adhere to organized rimfire match rules while providing maximum shot-to-shot consistency.



Integrated Extended Mag Release: Features Timney's single-finger release lever, allowing for lightning-fast, seamless magazine changes during timed stages.

True Drop-In Installation: Precision-engineered as a complete, self-contained module. Easily swaps with your factory trigger housing in minutes—no gunsmithing needed.

Custom Aesthetics: Customize your setup with your choice of a Black or Silver housing, paired with 6 vibrant trigger shoe color options (Black, Red, Blue, Gold, Green, or Silver).

Uncompromising USA Craftsmanship: Precision-machined from premium materials in Phoenix, Arizona, and backed by Timney's legendary No-Hassle Lifetime Warranty.

Attributes

- Name: RUGER 1022, GREEN SHOE-COMPETITION **3lb**
- Manufacturer: TIMNEY
- Product no.: EU2018781
- Mfr. No.: 1022-5C-COMP
- Colour: Green
- Model: 10/22
- Weapon type: Ruger
- Delivery weight: 0.09kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950252862

Table of Contents

- [Startpage](#)
- [English: RUGER 1022 Competition Trigger Complete Assembly Safety Instructions](#)

RUGER 1022 Competition Trigger Complete Assembly Safety Instructions

Introduction

Thank you for choosing the RUGER 1022 Competition Trigger Complete Assembly. This product is designed to enhance your shooting experience while ensuring safety and compliance with EU regulations. This guide provides essential safety instructions, installation guidelines, and contact information for further support.

General Safety Guidelines

- Ensure that you are familiar with the operation of your firearm and its components before attempting to install or use this product.
- Always treat every firearm as if it is loaded. Keep the muzzle pointed in a safe direction and your finger off the trigger until ready to shoot.
- Store your firearm and this trigger assembly in a secure location, out of reach of children and unauthorized users.
- Be aware of your surroundings and ensure that your shooting area is clear of people and obstacles.
- Regularly inspect your firearm and trigger assembly for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding firearm usage and modifications.

Specific Safety Precautions for Use

- This trigger assembly is intended for use with the RUGER 1022 model only. Do not attempt to use it with any other firearm.
- The factory preset pull weight of this trigger assembly is 3 lbs. Ensure you are comfortable with this weight before use.
- If you are new to firearms or trigger modifications, seek guidance from a qualified firearms instructor or gunsmith.
- Always wear appropriate eye and ear protection while shooting.
- Never engage in shooting activities under the influence of alcohol or drugs.

Instructions for Installation and Usage

Installation

1. Preparation:

- Ensure that the firearm is unloaded and the magazine is removed.
- Gather necessary tools: a screwdriver and any other tools specified in your firearm's manual.

2. Remove the Factory Trigger Housing:

- Locate the trigger housing on your RUGER 1022.
- Carefully unscrew and remove the factory trigger housing.

3. Install the RUGER 1022 Competition Trigger Assembly:

- Align the new trigger assembly with the housing area.
- Gently insert the assembly and ensure it is seated properly.
- Secure the assembly using the screws removed earlier.

4. Test Functionality:

- Before using the firearm, perform a function check to ensure the trigger operates correctly.
- Ensure that the safety mechanisms are functioning properly.

Usage

- After installation, familiarize yourself with the trigger's operation.
- Practice shooting in a controlled environment to gain confidence with the new trigger pull weight.
- Regularly maintain your firearm and the trigger assembly to ensure optimal performance.

Disposal Instructions

- Dispose of any packaging materials in accordance with local waste disposal regulations.
- If you need to dispose of the trigger assembly, check with local authorities for proper disposal methods to ensure environmental safety.

Contact Information for Further Support

For safety inquiries or support regarding this product, please refer to the official website or customer service for assistance. Always ensure you are using the most up-to-date information and guidelines.

By following these safety instructions, you can ensure a safe and enjoyable experience with your RUGER 1022 Competition Trigger Complete Assembly. Always prioritize safety and responsibility while handling firearms.