

RUGER 1022 Competition Trigger Complete Assembly - RUGER 1022, SILVER SHOE-COMPETITION ****3lb****

Match-Compliant Pull Weight: Factory preset to a crisp 3 lbs. to strictly adhere to organized rimfire match rules while providing maximum shot-to-shot consistency.



Integrated Extended Mag Release: Features Timney's single-finger release lever, allowing for lightning-fast, seamless magazine changes during timed stages.

True Drop-In Installation: Precision-engineered as a complete, self-contained module. Easily swaps with your factory trigger housing in minutes—no gunsmithing needed.

Custom Aesthetics: Customize your setup with your choice of a Black or Silver housing, paired with 6 vibrant trigger shoe color options (Black, Red, Blue, Gold, Green, or Silver).

Uncompromising USA Craftsmanship: Precision-machined from premium materials in Phoenix, Arizona, and backed by Timney's legendary No-Hassle Lifetime Warranty.

Attributes

- Name: RUGER 1022, SILVER SHOE-COMPETITION ****3lb****
- Manufacturer: TIMNEY
- Product no.: EU2018782
- Mfr. No.: 1022-6C-COMP
- Colour: Silver
- Model: 10/22
- Weapon type: Ruger
- Delivery weight: 0.09kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950262861

Table of Contents

- [Startpage](#)
- [English: RUGER 1022 Competition Trigger Complete Assembly Safety Instructions](#)

RUGER 1022 Competition Trigger Complete Assembly Safety Instructions

Introduction

Thank you for choosing the RUGER 1022 Competition Trigger Complete Assembly. This product is designed to enhance your shooting experience with a matchcompliant pull weight and easy installation. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always handle firearms with care and treat every firearm as if it is loaded.
- Ensure that the firearm is pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Store your firearm and ammunition in a secure location, out of reach of children and unauthorized users.
- Familiarize yourself with the local laws and regulations regarding firearm ownership and use.
- Regularly inspect your firearm and accessories for signs of wear or damage.
- Always wear appropriate safety gear, including eye and ear protection, when using firearms.

Specific Safety Precautions for Use

- Ensure the trigger assembly is compatible with your RUGER 1022 model before installation.
- Do not attempt to modify the trigger assembly beyond the manufacturer's specifications.
- Use caution when handling the trigger assembly, as sharp edges may be present.
- Ensure that the firearm is completely unloaded before installing or removing the trigger assembly.
- Do not use the firearm if the trigger assembly has been damaged or improperly installed.
- If you experience any malfunctions or irregularities during use, cease operation immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Unloading the Firearm

- Ensure the firearm is pointed in a safe direction.
- Remove the magazine and check the chamber to confirm that it is empty.

2. Removing the Factory Trigger Housing

- Use an appropriate tool to remove the screws securing the factory trigger housing.
- Carefully detach the factory trigger housing from the firearm.

3. Installing the RUGER 1022 Competition Trigger Assembly

- Align the new trigger assembly with the mounting points of the firearm.
- Secure the trigger assembly in place using the screws provided.
- Ensure that the assembly is firmly attached and does not move.

4. Testing the Trigger

- With the firearm still unloaded, test the trigger pull to ensure it operates smoothly.
- Make any necessary adjustments according to the manufacturer's instructions.

5. Using the Firearm

- After installation, always check that the firearm is functioning properly before use.
- Follow all safety guidelines and best practices when operating the firearm.

Disposal Instructions

- Dispose of the trigger assembly in accordance with local laws and regulations.
- Do not discard the trigger assembly in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

- For any inquiries regarding the product, please refer to the manufacturer's website or contact their customer service for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your RUGER 1022 Competition Trigger Complete Assembly. Always prioritize safety and responsibility when handling firearms.