

RUGER 1022 SILVER Competition Trigger Complete Assembly - RUGER 1022 SILVER HOUSING, GREEN SHOE-COMPETITION **3lb**

Match-Compliant Pull Weight: Factory preset to a crisp 3 lbs. to strictly adhere to organized rimfire match rules while providing maximum shot-to-shot consistency.



Integrated Extended Mag Release: Features Timney's single-finger release lever, allowing for lightning-fast, seamless magazine changes during timed stages.

True Drop-In Installation: Precision-engineered as a complete, self-contained module. Easily swaps with your factory trigger housing in minutes—no gunsmithing needed.

Custom Aesthetics: Customize your setup with your choice of a Black or Silver housing, paired with 6 vibrant trigger shoe color options (Black, Red, Blue, Gold, Green, or Silver).

Uncompromising USA Craftsmanship: Precision-machined from premium materials in Phoenix, Arizona, and backed by Timney's legendary No-Hassle Lifetime Warranty.

Attributes

- Name: RUGER 1022 SILVER HOUSING, GREEN SHOE-COMPETITION **3lb**
- Manufacturer: TIMNEY
- Product no.: EU2018787
- Mfr. No.: 1022-5C-16-COMP
- Colour: Green
- Model: 10/22
- Weapon type: Ruger
- Delivery weight: 0.23kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950526864

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for RUGER 1022 SILVER Competition Trigger Complete Assembly](#)

Safety Instruction Guide for RUGER 1022 SILVER Competition Trigger Complete Assembly

Introduction

Thank you for choosing the RUGER 1022 SILVER Competition Trigger Complete Assembly. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of your product. Please read this document carefully to understand how to handle and maintain your trigger assembly properly.

General Safety Guidelines

- **Product Safety:** Ensure the safe use of this product by following all instructions provided in this guide. This product complies with the EU General Product Safety Regulation (GPSR).
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to this product. If a recall occurs, you will be provided with standardized information and free remedies.
- **Online Shopping:** If you purchased this product online, rest assured that it meets the same safety standards as those sold in physical stores.
- **Special Consumer Focus:** Extra precautions are in place for vulnerable groups. Keep this product out of reach of children.
- **EU Contact Point:** For any safety inquiries, refer to the contact information provided with your product.
- **Rapid Alerts:** Be aware of updates on unsafe products through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before installing or handling the trigger assembly.
- Do not modify the trigger assembly in any way that could affect its performance or safety.
- Use only compatible firearms as specified in the product specifications.
- Regularly inspect the trigger assembly for any signs of wear or damage.
- Store the product in a dry, secure location away from unauthorized access.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure that the firearm is completely unloaded and the safety is engaged.
2. **Remove the Factory Trigger Housing:**
 - Follow the manufacturer's instructions to safely remove the existing trigger housing.
3. **Install the RUGER 1022 SILVER Trigger Assembly:**
 - Align the new trigger assembly with the housing.
 - Carefully insert the assembly, ensuring it is seated correctly.
4. **Secure the Assembly:**
 - Follow the specific instructions to secure the trigger assembly in place.
5. **Check Functionality:**
 - After installation, ensure that the trigger operates smoothly before using the firearm.

Usage

- Familiarize yourself with the operation of the trigger assembly before using the firearm in any capacity.
- Always follow safe firearm handling practices.
- Be aware of the trigger pull weight of 3 lbs, which is designed for maximum shot consistency.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous materials.
- Do not dispose of the product in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.

Contact Information for Further Support

For any further inquiries or support regarding the RUGER 1022 SILVER Competition Trigger Complete Assembly, please refer to the contact information provided with your product.

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your RUGER 1022 SILVER Competition Trigger Complete Assembly. Thank you for your attention to safety.