

Furiosa Chassis Remington 700 SA AICS Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Remington 700 SA AICS Walnut
- Manufacturer: WOOX
- Product no.: EU2018799
- Mfr. No.: SH.CHS011.05
- Colour: Walnut
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393056

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Remington 700 SA AICS. This innovative hybrid rifle stock combines classic aesthetics with modern tactical performance. To ensure safe and effective use of your product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure safe use of the WOOX Furiosa Chassis by adhering to the following guidelines:
 - Always treat your rifle with respect and follow all firearm safety rules.
 - Keep the chassis and rifle securely stored when not in use.
 - Regularly inspect the chassis for any signs of wear or damage.
 - Be aware of your surroundings and ensure that you are in a safe environment when using your rifle.
 - Ensure that all accessories used with the chassis are compatible and securely attached.
 - Follow local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- When using the WOOX Furiosa Chassis, please observe the following precautions:
 - Always use the chassis in conjunction with a properly functioning Remington 700 SA AICS rifle.
 - Avoid placing your fingers on the trigger until you are ready to fire.
 - Use appropriate eye and ear protection while shooting.
 - Ensure that the adjustable Length of Pull (LOP) is set correctly before use.
 - Be cautious when using the MicroAdjustable Cheek Riser to avoid pinching skin or causing injury.
 - Do not modify the chassis or its components, as this may compromise safety and performance.
 - Ensure that the MLOK® slots are used correctly to prevent accessory failure.

Instructions for Installation and Usage

- Follow these steps for proper installation and usage of the WOOX Furiosa Chassis:
 1. **Installation:**
 - Carefully remove the existing stock from your Remington 700 SA AICS rifle.
 - Align the action of the rifle with the chassis and insert it into the aluminum skeleton.
 - Secure the action using the provided screws, ensuring they are tightened to the manufacturer's specifications.
 - Attach any desired accessories to the MLOK® slots and Picatinny rail, ensuring they are securely fastened.
 2. **Adjustments:**
 - To adjust the Length of Pull (LOP), locate the pushbutton mechanism and press it while sliding the buttstock to the desired length (13.5" to 15").
 - For the MicroAdjustable Cheek Riser, loosen the adjustment knob, position the riser for comfort, and tighten the knob securely.
 3. **Usage:**
 - Always check the rifle's safety mechanism before handling.
 - Practice safe shooting techniques and maintain control of the rifle at all times.
 - After use, clean the chassis and rifle according to the manufacturer's recommendations.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in an environmentally responsible manner:
 - Do not dispose of the chassis in regular household waste.

- Check local regulations for the proper disposal of aluminum and wood materials.
- Consider recycling the chassis components where possible.

Contact Information for Further Support

- For any inquiries or concerns regarding the WOOX Furiosa Chassis, please refer to the contact information provided by your retailer or manufacturer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Always prioritize safety and responsible firearm use. Thank you for choosing WOOX.