

# Furiosa Chassis Remington 700 SA AICS Micarta

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

**Aerospace-Grade Aluminum Core:** Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

**Micro-Adjustable Cheek Riser:** Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

**Adjustable Length of Pull (LOP):** Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

**M-LOK® Forend:** Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

**Integrated Picatinny Rail:** Bottom-mounted rail section for monopods and rear support accessories.

**QD Sling Mounts:** Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE  
AVAILABLE

## Attributes

- Name: WOOX Furiosa Chassis Remington 700 SA AICS Micarta
- Manufacturer: WOOX
- Product no.: EU2018801
- Mfr. No.: SH.CHS013.05
- Colour: Micarta
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393070

# Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

# WOOX Furiosa Chassis Safety Instruction Guide

## Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Remington 700 SA AICS Micarta. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your product. Please read this document carefully and keep it for future reference.

## General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always follow the manufacturer's instructions for use and maintenance.
- Regularly inspect the chassis for any signs of wear or damage before use.
- Store the chassis in a safe, dry place when not in use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents to the relevant authorities.

## Specific Safety Precautions for Use

- **Firearm Safety:** Always treat firearms as if they are loaded. Follow all firearm safety rules.
- **Proper Handling:** Use the chassis only with compatible firearms. Ensure the firearm is properly secured in the chassis.
- **Recoil Management:** Be aware of the recoil when firing. Ensure you are in a stable position to manage recoil effectively.
- **Environmental Conditions:** Avoid using the chassis in extreme weather conditions that may affect performance.
- **Personal Protective Equipment:** Wear appropriate safety gear, including eye and ear protection, when using firearms.

## Instructions for Installation and Usage

### 1. Installation:

- Carefully remove the chassis from its packaging.
- Inspect all components for damage or defects.
- Follow these steps for installation:
  - Ensure the firearm is unloaded and pointed in a safe direction.
  - Align the firearm with the chassis, ensuring proper fit.
  - Secure the firearm in the chassis using the provided mechanisms.
  - Adjust the length of pull (LOP) using the pushbutton mechanism.
  - Finetune the cheek riser for optimal scope alignment.

### 2. Usage:

- Before firing, ensure that the chassis is securely attached to the firearm.
- Adjust the MLOK® forend as needed for accessories.
- Use the integrated Picatinny rail for mounting additional equipment.
- Practice safe shooting techniques and always be aware of your surroundings.

## Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the chassis in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.

## **Contact Information for Further Support**

For any inquiries or support regarding the WOOX Furiosa Chassis, please refer to the manufacturer's website or contact their customer service for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for prioritizing safety and responsible usage.