

Furiosa Chassis Remington 700 SA / Left Hand AICS Walnut

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: [WOOX Furiosa Chassis Remington 700 SA / Left Hand AICS Walnut](#)
- Manufacturer: [WOOX](#)
- Product no.: EU2018802
- Mfr. No.: SH.CHS011.05LH
- Colour: Walnut
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393087

Table of Contents

- [Startpage](#)
- [WOOX Furiosa Chassis Safety Instruction Guide](#)
- [About Us](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Remington 700 SA / Left Hand AICS. This product is designed to provide you with a perfect blend of classic aesthetics and modern tactical performance. To ensure your safety and the optimal performance of your chassis, please read and follow this safety instruction guide carefully.

General Safety Guidelines

- Ensure safe use of the WOOX Furiosa Chassis by adhering to the following guidelines:
 - Always handle firearms responsibly and in accordance with local laws and regulations.
 - Keep the chassis and rifle out of reach of children and unauthorized users.
 - Regularly inspect the chassis for signs of wear or damage before use.
 - Familiarize yourself with all components of the chassis and their functions.
 - Use only compatible accessories and components as specified by the manufacturer.
 - Store the chassis in a cool, dry place to prevent deterioration of materials.
 - Do not modify the chassis or its components without consulting the manufacturer.
 - In case of any malfunction or unusual operational behavior, cease use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Before using the WOOX Furiosa Chassis, please observe the following precautions:
 - Always wear appropriate eye and ear protection when shooting.
 - Ensure the firearm is unloaded when attaching or detaching the chassis.
 - Doublecheck that all screws and attachments are secure prior to use.
 - Be aware of your surroundings and ensure a clear line of sight when shooting.
 - Do not exceed the recommended length of pull (LOP) adjustments to maintain stability and control.
 - Make sure that the microadjustable cheek riser is securely locked in place before shooting.
 - Use the MLOK® accessory slots and Picatinny rail as intended to avoid accidents.

Instructions for Installation and Usage

- Follow these steps for the proper installation and usage of your WOOX Furiosa Chassis:

1. Installation:

- Ensure the firearm is unloaded.
- Remove the original stock from the Remington 700 SA.
- Align the WOOX Furiosa Chassis with the action of the rifle.
- Securely attach the chassis using the provided screws and tools.
- Adjust the length of pull (LOP) to your preference using the pushbutton mechanism.
- Finetune the cheek riser for optimal eye alignment with the scope.
- Attach any accessories to the MLOK® slots or Picatinny rail as needed.

2. Usage:

- Always check the stability of the chassis before shooting.
- Maintain a proper shooting stance and grip to ensure control.
- Regularly clean and maintain the chassis to ensure longevity.
- After use, store the chassis in a protective case to prevent damage.

Disposal Instructions

- When disposing of the WOOX Furiosa Chassis, please follow these guidelines:
 - Do not dispose of the chassis in regular household waste.
 - Contact local waste management authorities for proper disposal procedures.
 - Consider recycling components where possible, especially metal and wood materials.
 - Ensure that any accessories or attachments are also disposed of responsibly.

Contact Information for Further Support

- For any inquiries related to safety, installation, or product performance, please refer to the manufacturer's contact information provided with your product packaging.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for your attention to these important guidelines. Happy shooting!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk