

Furiosa Chassis Remington 700 SA / Left Hand AICS Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Remington 700 SA / Left Hand AICS Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018803
- Mfr. No.: SH.CHS012.05LH
- Colour: Laminated Tiger Wood
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393094

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This product is designed to enhance your shooting experience while ensuring safety and compliance with EU regulations. Please read this guide carefully to understand how to use the chassis safely and effectively.

General Safety Guidelines

- Always ensure that the firearm is unloaded before attaching or detaching the chassis.
- Use the chassis only for its intended purpose with compatible firearms.
- Keep the chassis and all firearm components away from children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure a secure fit between the chassis and the firearm to prevent any movement during use.
- Avoid using the chassis in wet or humid conditions to maintain the integrity of the materials.
- Be aware of your surroundings and ensure a safe shooting environment.
- Always wear appropriate safety gear, including eye and ear protection, when using firearms.
- Do not modify the chassis or firearm in any way that could compromise safety or performance.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is unloaded.
- Remove the existing stock from the firearm according to the manufacturer's instructions.
- Align the WOOX Furiosa Chassis with the firearm's action.
- Securely attach the chassis using the provided hardware, ensuring all screws are tightened to the manufacturer's specifications.

2. Adjusting Length of Pull (LOP)

- Locate the pushbutton mechanism on the chassis.
- Press the button while adjusting the LOP to your desired length (13.5" to 15" or 34.3 cm – 38.1 cm).
- Release the button to lock the adjustment in place.

3. Using the MicroAdjustable Cheek Riser

- Adjust the cheek riser to achieve a comfortable cheek weld.
- Ensure the riser is locked in place before use.

4. Attaching Accessories

- Use the MLOK® slots to attach accessories such as bipods or lights, ensuring they are securely mounted.
- For the integrated Picatinny rail, attach monopods or rear support accessories as needed.

5. Using QD Sling Mounts

- Attach your sling to the builtin Quick Detach sling swivel points for convenient carry options.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations.
- Do not dispose of the chassis in regular household waste. Instead, contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the WOOX Furiosa Chassis, please reach out to your local dealer or the manufacturer's customer service. Ensure you have the product details available for quicker assistance.

Thank you for following these safety guidelines. Your safety and satisfaction are our top priorities. Enjoy your shooting experience with the WOOX Furiosa Chassis!