

Furiosa Chassis Remington 700 SA / Left Hand AICS Micarta

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Remington 700 SA / Left Hand AICS Micarta
- Manufacturer: WOOX
- Product no.: EU2018804
- Mfr. No.: SH.CHS013.05LH
- Colour: Micarta
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393100

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This innovative product is designed to enhance your shooting experience while ensuring safety and performance. Please read this safety instruction guide carefully to understand how to use the Furiosa Chassis safely and effectively.

General Safety Guidelines

- Always follow local laws and regulations regarding firearm ownership and usage.
- Ensure that the WOOX Furiosa Chassis is compatible with your firearm model before installation.
- Regularly inspect your chassis and firearm for any signs of wear or damage.
- Store your firearm and chassis in a secure location, away from children and unauthorized individuals.
- Use the chassis only in a safe and controlled environment.
- Avoid using the chassis under extreme weather conditions, which may affect performance.

Specific Safety Precautions for Use

• Potential Hazards:

- Improper installation or use may lead to firearm malfunction or injury.
- The chassis may become loose over time; regular checks are necessary.

• Avoiding Hazards:

- Ensure all components are tightly secured before use.
- Do not exceed the recommended length of pull adjustments.
- Use the chassis only with the specified Remington 700 SA / Left Hand AICS configuration.

• AgeSpecific Warnings:

- This product is intended for use by adults. Keep it out of reach of children.
- Ensure that inexperienced users are supervised by knowledgeable individuals when using the chassis.

Instructions for Installation and Usage

1. Installation:

- Verify that the chassis is suitable for your firearm model.
- Remove the existing stock from your Remington 700 SA.
- Align the action of the firearm with the chassis and secure it using the provided screws.
- Ensure that the bedding system is properly seated to avoid any movement.

2. Adjusting Length of Pull (LOP):

- Locate the pushbutton mechanism on the chassis.
- Press the button and slide the buttstock to the desired length (between 13.5" and 15").
- Release the button to lock the buttstock in place.

3. Using the MicroAdjustable Cheek Riser:

- Adjust the cheek riser to achieve a comfortable cheek weld.

- Ensure it is locked in position before shooting.

4. Mounting Accessories:

- Use the MLOK® accessory slots to attach bipods, tripods, or lights.
- Ensure that all accessories are securely fastened before use.

5. Sling Attachment:

- Use the builtin QD sling mounts for attaching slings.
- Check that the sling is properly attached before carrying the firearm.

6. PostUse Care:

- Clean the chassis and inspect for any damage after each use.
- Store the chassis in a dry place to prevent material degradation.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations.
- Do not dispose of the chassis in regular household waste.
- Check with local authorities or waste management services for proper disposal methods.

Contact Information for Further Support

For safety inquiries or further support, please refer to the official WOOX website or your local authorized dealer. Always consult the manufacturer for the latest safety updates and product information.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for prioritizing safety and performance in your shooting activities.