

Furiosa Chassis Remington 700 SA BDL Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Remington 700 SA BDL Walnut
- Manufacturer: WOOX
- Product no.: EU2018808
- Mfr. No.: SH.CHS011.01
- Colour: Walnut
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393148

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Remington 700 SA BDL Walnut rifle. This product is designed with both classic aesthetics and modern tactical performance in mind. To ensure safe and effective use of your chassis, please read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Always treat your rifle as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Be aware of your surroundings and ensure that there is a safe backstop for your shots.
- Ensure that the rifle is secured when not in use to prevent unauthorized access, especially by children.
- Always wear appropriate eye and ear protection when shooting.
- Regularly inspect your chassis and firearm for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- **MicroAdjustable Cheek Riser:** When adjusting the cheek riser, ensure that your fingers are clear of any moving parts to avoid pinching.
- **Adjustable Length of Pull (LOP):** Always check that the LOP is securely locked in place before use. An improperly secured LOP can affect shooting stability.
- **MLOK® Forend:** Ensure that any accessories mounted to the MLOK® slots are securely attached to prevent them from coming loose during use.
- **QD Sling Mounts:** When using the Quick Detach sling mounts, ensure that the sling is properly attached and that the mount is functioning correctly to prevent accidental detachment.
- **Integrated Picatinny Rail:** Ensure that any accessories mounted on the Picatinny rail are compatible and securely fastened to avoid accidents.

Instructions for Installation and Usage

1. Installation:

- Carefully remove the chassis from its packaging.
- Ensure that the firearm is unloaded and the safety is engaged.
- Follow the manufacturer's instructions for attaching the chassis to your Remington 700 SA BDL rifle.
- Ensure that all screws and fittings are tightened securely.

2. Usage:

- Adjust the Length of Pull (LOP) to your preferred setting using the pushbutton mechanism.
- Adjust the MicroAdjustable Cheek Riser for optimal eye alignment with your scope.
- Attach any accessories to the MLOK® forend and Picatinny rail as needed.
- Before shooting, perform a function check to ensure that all adjustments are secure and the rifle operates correctly.

Disposal Instructions

- Dispose of the chassis in accordance with local regulations.
- Do not dispose of the chassis in regular household waste.
- Contact your local waste management authority for guidance on safe disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's website or contact the EU-based support center. Always ensure that you have the product details ready when seeking assistance.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your WOOX Furiosa Chassis. For your safety and the safety of others, always prioritize responsible firearm handling and maintenance practices. Thank you for your attention to these guidelines, and enjoy your shooting experience!