

Furiosa Chassis Remington 700 LA BDL Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Remington 700 LA BDL Walnut
- Manufacturer: WOOX
- Product no.: EU2018811
- Mfr. No.: SH.CHS011.02
- Colour: Walnut
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393728

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Remington 700 LA BDL Walnut rifle. This guide provides essential safety instructions and guidelines to ensure your safe and effective use of this product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that the WOOX Furiosa Chassis is installed correctly to avoid any accidental discharges or malfunctions.
- Always treat your firearm as if it is loaded, even when you believe it is not.
- Keep the firearm pointed in a safe direction at all times.
- Store the chassis and firearm in a secure location, away from children and unauthorized users.
- Regularly inspect your chassis and rifle for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm usage and storage.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is intended for use by individuals aged 18 and older. Ensure that minors are supervised by a responsible adult when handling firearms.
- **Firearm Compatibility:** Ensure that the WOOX Furiosa Chassis is compatible with your specific model of the Remington 700 LA BDL before installation.
- **Personal Protective Equipment:** Always wear appropriate safety gear, including eye protection and hearing protection when using your firearm.
- **Environmental Awareness:** Be aware of your surroundings and ensure that you are in a safe environment for shooting. Avoid shooting in areas where there may be bystanders or where it is prohibited.

Instructions for Installation and Usage

1. Installation of the Chassis:

- Remove the existing stock from your Remington 700 LA BDL.
- Carefully align the action of the rifle with the WOOX Furiosa Chassis.
- Secure the action using the provided screws, ensuring they are tightened to the manufacturer's specifications.
- Check that the chassis is firmly attached and that there is no movement.

2. Adjusting Length of Pull (LOP):

- To adjust the length of pull, locate the pushbutton mechanism on the chassis.
- Press the button and slide the buttstock to the desired length (between 13.5" and 15").
- Release the button to lock the buttstock in place.

3. MicroAdjustable Cheek Riser:

- Adjust the cheek riser by loosening the adjustment screw.
- Position the riser to achieve optimal cheek weld for your shooting style.
- Tighten the screw to secure the riser in place.

4. Using MLOK® Forend:

- Attach accessories such as bipods or lights to the MLOK® slots by aligning the accessory with the slot.
- Slide the accessory into the slot and secure it according to the accessory manufacturer's instructions.

5. Using QD Sling Mounts:

- Attach your sling to the builtin Quick Detach (QD) mounts by pressing the button and inserting the sling swivel.
- Ensure that the sling is securely attached before use.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations for electronic waste and materials.
- Do not dispose of the chassis in regular household waste. Instead, take it to a designated recycling facility or hazardous waste disposal site.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's website or contact your local retailer for assistance. Always ensure that you have the latest information regarding recalls or safety notices.

Conclusion

Your safety and the safety of others is of utmost importance. By following these guidelines, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Always stay informed about safety practices and local regulations regarding firearm usage. Thank you for your attention to these safety instructions.