

Furiosa Chassis Remington 700 LA BDL Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Remington 700 LA BDL Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018812
- Mfr. No.: SH.CHS012.02
- Colour: Laminated Tiger Wood
- Model: 700
- Weapon type: Remington
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393179

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instructions](#)

WOOX Furiosa Chassis Safety Instructions

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Remington 700 LA BDL. This hybrid rifle stock is designed to provide both classic aesthetics and modern tactical performance. To ensure safe and effective use of this product, please read and follow all safety instructions carefully.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Ensure that the WOOX Furiosa Chassis is installed correctly before use.
- Regularly inspect your chassis and firearm for any signs of wear or damage.
- Keep the chassis and firearm out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding firearm ownership and use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Handling:** Always handle your firearm with care. Use proper grip and stance while aiming and shooting.
- **Installation:** Ensure that the chassis is securely attached to the firearm before each use. Loose fittings can lead to accidents.
- **Environment:** Avoid using the chassis in extreme weather conditions, such as heavy rain or snow, which can affect performance.
- **Maintenance:** Regularly clean and maintain both the chassis and the firearm to ensure optimal performance and safety.
- **Ammunition:** Use only the recommended ammunition type for your Remington 700 LA BDL. Incorrect ammunition can cause malfunction or injury.

Instructions for Installation and Usage

1. Installation of the WOOX Furiosa Chassis:

- Remove the existing stock from your Remington 700 LA BDL.
- Align the WOOX Furiosa Chassis with the action of the rifle.
- Securely fasten the chassis using the provided screws, ensuring that all connections are tight.
- Verify that the chassis is properly seated and does not move.

2. Adjusting Length of Pull (LOP):

- Locate the pushbutton mechanism on the chassis.
- Press the button and adjust the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) as needed.
- Release the button to lock the adjustment in place.

3. Using the MicroAdjustable Cheek Riser:

- Adjust the cheek riser for optimal eye alignment with your scope.
- Ensure that the riser is securely locked in position before use.

4. Utilizing MLOK® Forend:

- Attach accessories such as bipods or lights to the MLOK® slots located at 3, 6, and 9 o'clock positions.

- Ensure that all accessories are firmly secured before use.

5. Using the Integrated Picatinny Rail:

- Mount monopods or rear support accessories onto the bottommounted rail section.
- Confirm that all mounts are secure prior to usage.

6. QD Sling Mounts:

- Attach your sling to the builtin Quick Detach sling swivel points.
- Ensure that the sling is properly secured and allows for flexible carry options.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations.
- Do not dispose of the chassis in regular household waste. Check for recycling options or designated disposal sites for firearms accessories.
- Ensure that all components are rendered safe and unusable before disposal.

Contact Information for Further Support

For any inquiries or concerns regarding the WOOX Furiosa Chassis, please contact the manufacturer or refer to the product documentation provided. Ensure to have your product details ready for a more efficient response.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for prioritizing safety!