

Furiosa Chassis Sauer 100 DBM Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Sauer 100 DBM Walnut
- Manufacturer: WOOX
- Product no.: EU2018820
- Mfr. No.: SH.CHS011.03
- Colour: Walnut
- Model: 100
- Weapon type: Sauer
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393254

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for purchasing the WOOX Furiosa Chassis. This guide provides essential safety instructions and guidelines to ensure safe and effective use of your new rifle stock. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure that the WOOX Furiosa Chassis is used only by individuals who are trained in firearm safety and handling.
- Always treat firearms as if they are loaded, even when they are not.
- Keep the firearm pointed in a safe direction at all times.
- Store the chassis and firearm securely, out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of damage or wear. Do not use if damaged.
- Ensure that all accessories and attachments are securely fastened before use.
- Follow all local laws and regulations regarding firearm use and ownership.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is intended for use by individuals aged 18 years and older. Ensure that minors are supervised by a responsible adult when handling firearms.
- **Environmental Conditions:** Avoid using the chassis in extreme weather conditions that may affect performance, such as heavy rain or excessive heat.
- **Stability:** Ensure that the rifle is stable and secure before firing. Use a stable shooting platform whenever possible.
- **Recoil Management:** Be prepared for recoil when firing, and ensure that your stance is stable to maintain control of the firearm.
- **Accessory Compatibility:** Only use accessories that are compatible with the WOOX Furiosa Chassis to avoid accidents or malfunctions.

Instructions for Installation and Usage

Installation

1. Prepare the Chassis:

- Remove any existing stock from your rifle.
- Clean the rifle to remove dirt or debris that may interfere with installation.

2. Install the Chassis:

- Align the rifle action with the WOOX Furiosa Chassis.
- Securely fasten the action to the chassis using the provided screws and tools.
- Ensure that the chassis is tightly secured to prevent movement during use.

3. Adjust the Cheek Riser:

- Adjust the microadjustable cheek riser to achieve a comfortable cheek weld.
- Ensure that the adjustment is secure before use.

4. Adjust the Length of Pull (LOP):

- Use the pushbutton mechanism to adjust the LOP from 13.5" to 15".

- Confirm that the adjustment is locked in place before proceeding.

5. Attach Accessories:

- Utilize the MLOK® accessory slots to attach any desired accessories.
- Ensure all attachments are securely fastened.

Usage

- Always follow firearm safety rules when using the WOOX Furiosa Chassis.
- Maintain a proper shooting stance to ensure stability and control.
- Regularly check the chassis and firearm for any signs of wear or malfunction during use.
- Clean the chassis according to the manufacturer's recommendations to ensure optimal performance.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations.
- If the chassis is damaged beyond repair, ensure that it is rendered unusable before disposal.
- Recycle materials when possible, following local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's contact information provided with your purchase. It is important to have access to support for any safety inquiries or product-related issues.

Thank you for choosing the WOOX Furiosa Chassis. Your safety and satisfaction are our top priorities. Please adhere to these guidelines for a safe and enjoyable experience.