

Furiosa Chassis Sauer 100 DBM Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Sauer 100 DBM Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018821
- Mfr. No.: SH.CHS012.03
- Colour: Laminated Tiger Wood
- Model: 100
- Weapon type: Sauer
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393261

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instructions](#)

WOOX Furiosa Chassis Safety Instructions

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This product is designed to enhance your shooting experience while ensuring safety and performance. Please read this manual carefully to understand the safety guidelines, installation procedures, and usage instructions.

General Safety Guidelines

- Always treat your firearm and accessories as if they are loaded.
- Ensure that you are in a safe environment when handling the chassis and your firearm.
- Keep your finger off the trigger until ready to shoot.
- Store the chassis and any associated firearms securely and out of reach of children.
- Regularly inspect the chassis for any signs of wear or damage before use.
- Do not modify the chassis or any components without consulting a qualified gunsmith.
- Be aware of your surroundings and ensure that your shooting area is clear of people and obstacles.

Specific Safety Precautions for Use

- **AerospaceGrade Aluminum Core:** Ensure that the chassis is properly mounted to avoid any instability during use.
- **MicroAdjustable Cheek Riser:** Adjust the cheek riser only when the firearm is pointed in a safe direction.
- **Adjustable Length of Pull (LOP):** Make adjustments to the LOP while the firearm is pointed in a safe direction.
- **MLOK® Forend:** Only attach accessories that are compatible with the MLOK® system and rated for use with your chassis.
- **QD Sling Mounts:** Ensure that sling mounts are securely fastened before use to prevent accidental detachment.

Instructions for Installation and Usage

1. Installation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Remove the existing stock from your firearm according to the manufacturer's instructions.
- Align the WOOX Furiosa Chassis with the firearm's action and securely attach it using the provided hardware.
- Check that all screws and fasteners are tightened according to the specifications provided in the installation manual.

2. Usage:

- Adjust the Length of Pull (LOP) using the pushbutton mechanism to suit your comfort.
- Finetune the cheek riser for optimal scope alignment.
- Mount any accessories to the MLOK® slots, ensuring they are securely attached.
- Use the integrated Picatinny rail for additional support accessories as needed.

Disposal Instructions

- Dispose of the chassis and any components in accordance with local regulations.
- Do not dispose of the chassis in household waste. Check for local recycling programs or hazardous waste disposal sites.

- Ensure that any firearm attached to the chassis is properly disposed of according to legal requirements.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please consult your retailer or visit the manufacturer's website for additional resources and support.

By adhering to these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for prioritizing safety and responsible usage.