

Furiosa Chassis Sauer 100 DBM Micarta

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Sauer 100 DBM Micarta
- Manufacturer: WOOX
- Product no.: EU2018822
- Mfr. No.: SH.CHS013.03
- Colour: Micarta
- Model: 100
- Weapon type: Sauer
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393278

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This product is designed to enhance your shooting experience while ensuring safety and performance. Please read this safety instruction guide carefully to understand how to use the chassis safely and effectively.

General Safety Guidelines

- Always treat the chassis and firearm with respect and handle them as if they are loaded.
- Ensure that you are familiar with the specific laws and regulations regarding firearms and accessories in your area.
- Keep the chassis and all firearm components out of reach of children and unauthorized users.
- Inspect the chassis for any damages or defects before each use.
- Do not modify the chassis or any components without consulting a qualified professional.
- Use only compatible accessories and components as specified by the manufacturer.
- Always wear appropriate safety gear, including eye and ear protection, when using firearms.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper installation or use may lead to accidents or injuries.
 - Failure to secure the chassis properly can result in instability during shooting.
 - Exposure to extreme temperatures or humidity may affect the performance of the materials.
- **Instructions for Avoiding Hazards:**
 - Follow all installation instructions carefully to ensure proper fitting.
 - Regularly check the stability and integrity of the chassis before use.
 - Store the chassis in a cool, dry place to maintain material integrity.
- **Age or Audience Specific Warnings:**
 - This product is intended for adult users only. Keep it away from children.
 - Ensure that inexperienced users receive proper training before handling the chassis and firearm.

Instructions for Installation and Usage

1. Installation:

- Ensure that the firearm is unloaded and the safety is engaged before beginning installation.
- Follow the manufacturer's instructions to attach the chassis to the firearm securely.
- Check all screws and attachments for tightness after installation.

2. Usage:

- Adjust the Length of Pull (LOP) using the pushbutton mechanism to fit your shooting style.
- Finetune the cheek weld using the MicroAdjustable Cheek Riser for optimal scope alignment.
- Use the MLOK® accessory slots to attach any additional equipment securely.
- Regularly check the mounting points and accessories for any signs of wear or looseness during use.

Disposal Instructions

- Dispose of the chassis in accordance with local regulations regarding metal and composite material disposal.
- Do not dispose of the chassis in regular household waste.
- If the chassis is damaged beyond repair, contact local recycling facilities for proper disposal methods.

Contact Information for Further Support

For any questions regarding the WOOX Furiosa Chassis, or to report unsafe products, please contact the manufacturer directly through their official channels. Ensure you have the product details ready for efficient assistance.

By following these safety guidelines and instructions, you can enjoy the full benefits of the WOOX Furiosa Chassis while ensuring a safe shooting experience. Thank you for your attention to safety!