

Furiosa Chassis Tikka T3/T3X DBM Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Tikka T3/T3X DBM Walnut
- Manufacturer: WOOX
- Product no.: EU2018823
- Mfr. No.: SH.CHS011.04
- Colour: Walnut
- Model: T3x
- Weapon type: Tikka
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393735

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This product is designed to enhance your shooting experience while ensuring safety and performance. Please read this safety instruction guide thoroughly to understand how to use the chassis safely and effectively.

General Safety Guidelines

- Always handle your rifle and chassis with care. Treat every firearm as if it is loaded.
- Ensure that the chassis is compatible with your firearm model (Tikka T3/T3X).
- Follow all local laws and regulations regarding firearm ownership and usage.
- Store the chassis and your firearm in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage before use.
- Be aware of your surroundings and ensure a safe shooting environment.

Specific Safety Precautions for Use

- **Firearm Compatibility:** Ensure that the WOOX Furiosa Chassis is correctly fitted to the Tikka T3/T3X model to avoid malfunctions.
- **Recoil Management:** Be prepared for recoil when firing. Ensure a stable shooting position to manage recoil effectively.
- **Cheek Riser Adjustment:** Make adjustments to the cheek riser only when the firearm is unloaded and pointed in a safe direction.
- **Length of Pull Adjustment:** Adjust the Length of Pull (LOP) only when the firearm is unloaded. Ensure the mechanism is functioning properly before use.
- **MLOK Accessory Use:** When attaching accessories to the MLOK forend, ensure they are securely fastened to avoid accidents.
- **Sling Mounts:** Use the builtin Quick Detach sling swivel points only with compatible slings to ensure secure carrying.

Instructions for Installation and Usage

1. Installation:

- Verify that the chassis is compatible with your Tikka T3/T3X model.
- Remove the original stock from your firearm following the manufacturer's instructions.
- Align the firearm with the WOOX Furiosa Chassis and securely attach it using the provided hardware.
- Ensure that all screws are tightened to the manufacturer's specifications.

2. Usage:

- Before using the chassis, adjust the cheek riser and Length of Pull to fit your shooting preference.
- Familiarize yourself with the controls and features of the chassis.
- Conduct a function check to ensure that the chassis operates correctly with your firearm.
- Always use the chassis in a safe and responsible manner, following all shooting range rules and guidelines.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations regarding waste management and recycling.

- Do not dispose of the chassis in regular household waste. Instead, contact local waste management facilities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's contact information provided with the product packaging or visit the manufacturer's website for additional resources.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Always prioritize safety and responsible firearm handling. Thank you for choosing WOOX. Enjoy your shooting experience!