

Furiosa Chassis Tikka T3/T3X DBM Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Tikka T3/T3X DBM Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018824
- Mfr. No.: SH.CHS012.04
- Colour: Laminated Tiger Wood
- Model: T3x
- Weapon type: Tikka
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393285

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Tikka T3/T3X rifle. This guide provides essential safety instructions to ensure the safe use and maintenance of your product. Please read this guide carefully to understand the proper handling and usage of the chassis.

General Safety Guidelines

- **Product Safety:** The WOOX Furiosa Chassis is designed to ensure safe use. Always follow the safety guidelines to minimize risks during operation.
- **Enhanced Recalls:** Stay informed about any recalls related to this product. In the event of a recall, follow the instructions provided to ensure your safety.
- **Online Shopping:** If purchased online, ensure the retailer complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** Extra caution should be taken when using the chassis around vulnerable groups, including children.
- **EU Contact Point:** For safety inquiries, please refer to the relevant EU contact points provided by the retailer or manufacturer.
- **Rapid Alerts:** Be aware of the Safety Gate system for timely updates on any unsafe products.

Specific Safety Precautions for Use

- **Read the Manual:** Always read and understand the user manual before using the WOOX Furiosa Chassis.
- **Inspect Before Use:** Regularly check the chassis for any signs of wear or damage. Do not use if any components are compromised.
- **Proper Handling:** Handle the chassis with care. Avoid dropping or subjecting it to impacts.
- **Secure Mounting:** Ensure that the chassis is securely mounted to the rifle before use. Loose fittings can lead to accidents.
- **Avoid Modifications:** Do not alter or modify the chassis in any way, as this may compromise safety and performance.
- **Store Safely:** When not in use, store the chassis in a secure location away from children and unauthorized users.

Instructions for Installation and Usage

1. Installation:

- Ensure your workspace is clean and free of distractions.
- Gather all necessary tools and components before starting.
- Follow these steps to install the chassis:
 - Remove the existing stock from your Tikka T3/T3X rifle.
 - Align the WOOX Furiosa Chassis with the rifle action.
 - Securely fasten the chassis to the rifle using the provided screws and tools.
 - Check that all screws are tightened to the manufacturer's specifications.

2. Usage:

- Adjust the Length of Pull (LOP) as needed using the pushbutton mechanism.
- Finetune the cheek riser for optimal scope alignment.
- Utilize the MLOK® forend for mounting accessories, ensuring they are securely attached.
- Always check the stability of the chassis before each use.

3. **PostUse Care:**

- Clean the chassis with a soft cloth to remove any dirt or debris.
- Store the chassis in a protective case when not in use.

Disposal Instructions

- **Environmentally Friendly Disposal:** Dispose of the WOOX Furiosa Chassis in accordance with local regulations. Do not dispose of it in regular household waste.
- **Recycling:** If possible, recycle the chassis or its components. Check with local recycling centers for appropriate procedures.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the contact information provided by the retailer or manufacturer. They can assist you with any safety inquiries or product issues.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for your attention to safety.