

Furiosa Chassis Tikka T3/T3X DBM Micarta

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm - 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: [WOOX Furiosa Chassis Tikka T3/T3X DBM Micarta](#)
- Manufacturer: [WOOX](#)
- Product no.: EU2018825
- Mfr. No.: SH.CHS013.04
- Colour: Micarta
- Model: T3x
- Weapon type: Tikka
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393292

Table of Contents

- [Startpage](#)
- [WOOX Furiosa Chassis Safety Instruction Guide](#)
- [About Us](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This product is designed to provide superior performance and reliability for shooters and hunters. To ensure your safety and the optimal use of the Furiosa Chassis, please read and follow this safety instruction guide carefully.

General Safety Guidelines

- Ensure that you are familiar with the operation of your firearm and its compatibility with the WOOX Furiosa Chassis.
- Always treat firearms as if they are loaded. Keep the muzzle pointed in a safe direction at all times.
- Store the chassis and your firearm safely and securely when not in use.
- Use appropriate safety gear, including eye and ear protection, when operating your firearm.
- Be aware of your surroundings and ensure that you have a clear and safe shooting area.
- Regularly inspect your chassis and firearm for any signs of wear or damage before use.
- Do not modify the chassis or firearm in any way that may compromise safety or performance.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is intended for use by individuals 18 years and older. Ensure that younger users are supervised by a responsible adult.
- **Compatibility:** Verify that the WOOX Furiosa Chassis is compatible with your Tikka T3/T3X model. Refer to the manufacturer's specifications.
- **Installation:** Follow the installation instructions carefully to avoid any potential hazards.
- **Use of Accessories:** When using accessories, such as bipods or lights, ensure they are securely attached and compatible with the chassis.
- **Recoil Management:** Properly adjust the cheek riser and length of pull to ensure a comfortable shooting position and effective recoil management.
- **Humidity and Temperature:** Be aware that changes in humidity and temperature can affect the performance of the chassis. Store it in a controlled environment when possible.

Instructions for Installation and Usage

Installation Instructions

1. **Unpack the Chassis:** Carefully remove the WOOX Furiosa Chassis from its packaging. Inspect for any visible damage.
2. **Check Compatibility:** Confirm that the chassis fits your Tikka T3/T3X model.
3. **Attach the Chassis:**
 - Align the subchassis with the firearm's action.
 - Secure the chassis using the provided screws and tools. Ensure all screws are tightened appropriately.
4. **Adjust the Length of Pull:**
 - Use the pushbutton mechanism to adjust the length of pull from 13.5" to 15" (34.3 cm – 38.1 cm).
5. **Set the Cheek Riser:**
 - Adjust the cheek riser to achieve a proper cheek weld for your scope alignment.

Usage Instructions

- Always ensure the firearm is unloaded before making adjustments to the chassis.
- For optimal performance, regularly check the tightness of all screws and fittings.
- When using the MLOK® forend, ensure that accessories are securely attached and do not obstruct your handling of the firearm.

- Utilize the integrated Picatinny rail for mounting additional accessories as needed.
- If using QD sling mounts, ensure that they are properly engaged before carrying the firearm.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis responsibly when it reaches the end of its life cycle.
- Follow local regulations for the disposal of firearm accessories.
- If the chassis is damaged beyond repair, consider recycling materials where possible.

Contact Information for Further Support

For any inquiries related to safety, installation, or usage of the WOOX Furiosa Chassis, please reach out to the appropriate contact point provided by the manufacturer. Ensure that you have your product details ready for a more efficient response.

Conclusion

Your safety is our priority. By following these guidelines and instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for your attention to safety, and happy shooting!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk