

# Furiosa Chassis Tikka T3/T3X CTR DBM Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

**Aerospace-Grade Aluminum Core:** Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

**Micro-Adjustable Cheek Riser:** Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

**Adjustable Length of Pull (LOP):** Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

**M-LOK® Forend:** Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

**Integrated Picatinny Rail:** Bottom-mounted rail section for monopods and rear support accessories.

**QD Sling Mounts:** Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE  
AVAILABLE

## Attributes

- Name: WOOX Furiosa Chassis Tikka T3/T3X CTR DBM Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018827
- Mfr. No.: SH.CHS012.17
- Colour: Laminated Tiger Wood
- Model: T3x
- Weapon type: Tikka
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069394480

# Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instructions](#)

# WOOX Furiosa Chassis Safety Instructions

## Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Tikka T3/T3X rifle. This product is designed to enhance your shooting experience while ensuring safety and performance. Please read this safety instruction guide carefully to understand how to use the Furiosa Chassis safely and effectively.

## General Safety Guidelines

- Always treat the rifle as if it is loaded, even when you believe it is not.
- Store the chassis and rifle in a secure location, out of reach of children and unauthorized users.
- Ensure that you are familiar with local laws and regulations regarding firearms and their accessories.
- Inspect the chassis regularly for any signs of wear or damage.
- Use only compatible components and accessories with the WOOX Furiosa Chassis.

## Specific Safety Precautions for Use

- Ensure that the rifle is unloaded before attaching or detaching the chassis.
- Use the MicroAdjustable Cheek Riser only when the rifle is in a stable position to avoid accidents.
- Adjust the Length of Pull (LOP) only when the rifle is pointed in a safe direction.
- When using the MLOK® Forend, ensure that all accessories are securely mounted to prevent them from falling off during use.
- Always use the QD Sling Mounts as intended and ensure they are securely fastened before use.
- Be cautious when handling the chassis, as sharp edges may be present.

## Instructions for Installation and Usage

### Installation

1. **Unloading the Rifle:** Ensure that the rifle is completely unloaded before beginning installation.
2. **Attaching the Chassis:**
  - Align the rifle's action with the chassis.
  - Securely fasten the action screws according to the manufacturer's specifications.
3. **Adjusting the Cheek Riser:**
  - Use the adjustment mechanism to set the cheek riser to your desired height.
  - Ensure it locks into place before use.
4. **Setting the Length of Pull (LOP):**
  - Use the pushbutton mechanism to adjust the LOP from 13.5" to 15".
  - Confirm that the adjustment is secure before handling the rifle.
5. **Mounting Accessories:**
  - Attach accessories to the MLOK® slots or the integrated Picatinny rail as needed.
  - Ensure all accessories are tightened and secure.

### Usage

- Always ensure a safe shooting environment.
- Use proper shooting stance and grip when handling the rifle.
- Follow all range rules and regulations during use.
- Regularly check the stability of the chassis during shooting sessions.

## Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations regarding electronic and metal

waste.

- Remove any nonrecyclable components before disposal.
- Consider donating the chassis if it is still in usable condition.

## **Contact Information for Further Support**

For any inquiries regarding safety or product support, please refer to the official WOOX website or your local authorized dealer. Always ensure you have the latest information regarding product recalls or safety updates.

Thank you for prioritizing safety and performance with your WOOX Furiosa Chassis. Enjoy your shooting experience responsibly.