

Furiosa Chassis Tikka T3/T3X CTR DBM Micarta

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Tikka T3/T3X CTR DBM Micarta
- Manufacturer: WOOX
- Product no.: EU2018828
- Mfr. No.: SH.CHS013.17
- Colour: Micarta
- Model: T3x
- Weapon type: Tikka
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069394497

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Tikka T3/T3X rifle. This guide provides essential safety instructions and guidelines to ensure the safe use and enjoyment of your product. Please read this manual carefully before using the chassis.

General Safety Guidelines

- Always handle firearms and their components with care and respect.
- Ensure that the rifle is unloaded before installing or adjusting the chassis.
- Store the chassis and firearm in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage.
- Follow all local laws and regulations regarding firearms and their accessories.
- If you are unsure about any aspect of using the chassis, consult a qualified professional.

Specific Safety Precautions for Use

- **Recoil Management:** Ensure that the chassis is properly installed to maximize recoil management. Improper installation may lead to increased recoil and affect accuracy.
- **MicroAdjustable Cheek Riser:** Adjust the cheek riser carefully to avoid pinching or injury. Ensure it is securely locked in place before use.
- **Adjustable Length of Pull (LOP):** When adjusting the LOP, make sure your fingers are clear of the mechanism to avoid injury.
- **MLOK® Forend:** Use only compatible accessories with the MLOK® system to prevent malfunction or damage.
- **QD Sling Mounts:** Regularly check the integrity of the sling mounts to ensure they are secure and can bear the weight of your equipment.
- **Environmental Conditions:** Be mindful of environmental conditions such as humidity and temperature, which can affect the performance of the chassis.

Instructions for Installation and Usage

1. Installation of the Chassis:

- Ensure the rifle is unloaded.
- Remove the original stock from the Tikka T3/T3X rifle.
- Align the action of the rifle with the aluminum skeleton of the Furiosa chassis.
- Secure the action using the provided screws, ensuring they are tightened to the manufacturer's specifications.

2. Adjusting the Length of Pull (LOP):

- Locate the pushbutton mechanism on the chassis.
- Press the button and slide the buttstock to the desired length (between 13.5" and 15").
- Release the button to lock the buttstock in place.

3. Adjusting the Cheek Riser:

- Loosen the adjustment knob on the cheek riser.
- Move the riser to the desired height for optimal scope alignment.
- Tighten the knob securely before use.

4. Mounting Accessories:

- For MLOK® slots, ensure the accessory is compatible and follow the manufacturer's instructions for mounting.
- For the integrated Picatinny rail, attach accessories securely and check for stability before use.

5. Routine Maintenance:

- Clean the chassis regularly to remove dirt and debris.
- Inspect all components for wear or damage and replace as necessary.

Disposal Instructions

- Dispose of the chassis and any components responsibly, following local regulations for electronic waste and materials.
- If the chassis is damaged beyond repair, contact your local waste management facility for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please reach out to your local dealer or authorized WOOX representative. They will provide the necessary support and guidance for your product.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for your attention to safety and your commitment to responsible firearm use.