

Furiosa Chassis Savage 110 SA DBM Micarta

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm - 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: [WOOX Furiosa Chassis Savage 110 SA DBM Micarta](#)
- Manufacturer: [WOOX](#)
- Product no.: EU2018831
- Mfr. No.: SH.CHS013.11
- Colour: Micarta
- Model: 110
- Weapon type: Savage
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393322

Table of Contents

- [Startpage](#)
- [WOOX Furiosa Chassis Safety Instruction Guide](#)
- [About Us](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This innovative hybrid rifle stock is designed for shooters and hunters who value both classic aesthetics and modern tactical performance. To ensure your safety and the optimal performance of your product, please read this safety instruction guide carefully before use.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the WOOX Furiosa Chassis by following all instructions and guidelines outlined in this document.
- **Enhanced Recalls:** Stay informed about any recall notices related to this product. If a recall occurs, you will receive information on how to remedy the situation at no cost.
- **Online Shopping:** If purchased online, ensure that the retailer complies with EU safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children. Keep it out of reach of minors.
- **EU Contact Point:** For any safety inquiries, contact the designated EU-based support team.
- **Rapid Alerts:** Regularly check the EU Safety Gate platform for updates on any unsafe products.

Specific Safety Precautions for Use

- **Age Restriction:** This product is intended for adult use only. Do not allow children to handle or use the WOOX Furiosa Chassis.
- **Handling:** Always handle the chassis with care. Ensure that the firearm is unloaded before attaching or detaching the chassis.
- **Maintenance:** Regularly inspect the chassis for any signs of wear or damage. Do not use if any components are compromised.
- **Environment:** Avoid using the chassis in extreme weather conditions that may affect its performance, such as heavy rain or extreme heat.
- **Storage:** Store the chassis in a cool, dry place when not in use to prevent damage.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is completely unloaded.
- Remove the existing stock from the firearm according to the manufacturer's instructions.
- Align the WOOX Furiosa Chassis with the firearm's action.
- Secure the chassis using the provided screws and tools, ensuring a tight fit.
- Attach any additional components, such as the cheek riser or adjustable length of pull, as needed.

2. Usage:

- Adjust the cheek riser for a comfortable and secure cheek weld. This can be done without additional tools.
- Modify the length of pull (LOP) as necessary, using the pushbutton mechanism to switch between 13.5" and 15" (34.3 cm – 38.1 cm).
- Utilize the MLOK® accessory slots for attaching bipods, tripods, or lights as needed.
- Ensure the integrated Picatinny rail is securely attached for any rear support accessories.

3. PostUse Maintenance:

- After each use, clean the chassis with a soft, dry cloth to remove dirt and moisture.

- Store the chassis in a protective case or designated storage area.

Disposal Instructions

- When the WOOX Furiosa Chassis has reached the end of its life cycle, dispose of it in accordance with local regulations for electronic and metal waste.
- Do not dispose of the chassis in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's website or contact your local retailer for assistance. Always ensure you comply with local laws and regulations when using and maintaining your firearm and accessories.

By following these guidelines, you can ensure safe and effective use of your WOOX Furiosa Chassis. Thank you for your attention to safety, and enjoy your shooting experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk