

Furiosa Chassis Savage 110 LA DBM Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Savage 110 LA DBM Walnut
- Manufacturer: WOOX
- Product no.: EU2018832
- Mfr. No.: SH.CHS011.12
- Colour: Walnut
- Model: 110
- Weapon type: Savage
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393339

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This guide provides essential safety instructions and guidelines to ensure the safe use of your product. Please read this document carefully before using the chassis to enhance your shooting experience while ensuring safety for yourself and others.

General Safety Guidelines

- Always handle firearms and firearm accessories with care and responsibility.
- Ensure that the WOOX Furiosa Chassis is installed correctly and securely before use.
- Be aware of your surroundings and ensure that you are in a safe environment when using the chassis.
- Follow all local laws and regulations regarding firearms and their accessories.
- Regularly inspect the chassis for any signs of wear or damage before each use.
- Store the chassis in a secure location, away from unauthorized users, especially children.
- If you notice any defects or issues with the chassis, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is intended for use by individuals aged 18 years and older. Ensure that minors are supervised when handling firearms and accessories.
- **Firearm Compatibility:** Confirm that the chassis is compatible with your specific firearm model (Savage 110) before installation.
- **Recoil Management:** Be aware of the recoil when firing. Ensure that you are positioned securely to manage the recoil effectively.
- **Cheek Weld Adjustment:** Use the microadjustable cheek riser carefully to avoid injury. Ensure it is securely locked in place before use.
- **Length of Pull Adjustment:** Adjust the Length of Pull (LOP) only when the firearm is not loaded. Ensure the adjustment mechanism is functioning correctly.
- **Accessory Mounting:** When attaching accessories to the MLOK® slots or Picatinny rail, ensure they are securely fastened and do not interfere with the operation of the firearm.
- **Sling Use:** When using the Quick Detach sling mounts, ensure that the sling is properly attached to avoid accidental detachment during use.

Instructions for Installation and Usage

1. Installation of the WOOX Furiosa Chassis:

- Ensure that your firearm is unloaded and pointed in a safe direction.
- Remove the existing stock from your Savage 110 according to the manufacturer's instructions.
- Align the action of your firearm with the WOOX Furiosa Chassis.
- Securely fasten the action to the chassis using the provided screws, ensuring a tight fit.
- Attach the microadjustable cheek riser and adjust it to your preference.
- Adjust the Length of Pull (LOP) as needed using the pushbutton mechanism.

2. Usage:

- Before using the chassis, verify that the firearm is properly secured and that all components are functioning as intended.
- Practice safe firearm handling at all times, including keeping the muzzle pointed in a safe direction and keeping your finger off the trigger until ready to shoot.
- When using the chassis in the field, regularly check that all components remain secure and functional.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations and guidelines.
- Do not dispose of the chassis in regular household waste.
- If the chassis is damaged beyond repair, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For safety inquiries or further assistance regarding the WOOX Furiosa Chassis, please reach out to your local dealer or authorized service center. Ensure that you have the product details ready for efficient support.

By following these safety guidelines and instructions, you can enjoy the benefits of the WOOX Furiosa Chassis while maintaining a safe environment for yourself and others. Thank you for your attention to safety!