

Furiosa Chassis Savage 110 LA DBM Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Savage 110 LA DBM Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018833
- Mfr. No.: SH.CHS012.12
- Colour: Laminated Tiger Wood
- Model: 110
- Weapon type: Savage
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393346

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for WOOX Furiosa Chassis Savage 110 LA DBM Laminated Tiger Wood](#)

Safety Instruction Guide for WOOX Furiosa Chassis Savage 110 LA DBM Laminated Tiger Wood

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This hybrid rifle stock is designed to provide both classic aesthetics and modern tactical performance. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always treat your rifle as if it is loaded, even when it is not.
- Keep the muzzle pointed in a safe direction at all times.
- Be aware of your surroundings and ensure that no one is in your line of fire.
- Use appropriate eye and ear protection when shooting.
- Ensure that you are familiar with local laws and regulations regarding firearm use.
- Store your rifle and chassis in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your chassis for wear and damage.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is intended for use by adults only. Ensure that minors are supervised by a responsible adult when using the rifle.
- **Proper Fit:** Adjust the Length of Pull (LOP) to fit your body size for optimal control and comfort.
- **MicroAdjustable Cheek Riser:** Ensure the cheek riser is properly adjusted before shooting to maintain proper scope alignment.
- **MLOK® Forend:** Be cautious when attaching accessories to the MLOK® slots. Ensure they are securely mounted to prevent accidents.
- **QD Sling Mounts:** Regularly check the integrity of the sling mounts to ensure they are not damaged or loose.

Instructions for Installation and Usage

1. Installation of the Chassis:

- Remove the existing stock from your Savage 110 rifle.
- Align the WOOX Furiosa Chassis with the rifle action.
- Securely fasten the chassis to the rifle using the provided screws and tools.
- Ensure all screws are tightened to the manufacturer's specifications.

2. Adjusting Length of Pull (LOP):

- Locate the pushbutton mechanism on the chassis.
- Press the button and slide the buttstock to the desired length (between 13.5" and 15").
- Release the button to lock the buttstock in place.

3. Adjusting the Cheek Riser:

- Loosen the adjustment knob located on the cheek riser.
- Slide the cheek riser up or down to achieve the desired height.
- Tighten the adjustment knob to secure the riser in place.

4. Mounting Accessories:

- Identify the MLOK® accessory slots on the forend.
- Use compatible MLOK® accessories and follow the manufacturer's instructions for mounting.
- Ensure all accessories are securely fastened before use.

5. Using the Integrated Picatinny Rail:

- Attach monopods or rear support accessories to the Picatinny rail as needed.
- Ensure that all attachments are properly secured to prevent movement during use.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations.
- Do not dispose of the chassis in regular household waste.
- Consider recycling components where possible, especially metal parts.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's website or customer service for assistance.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the WOOX Furiosa Chassis!