

Furiosa Chassis Savage 110 LA DBM Micarta

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Savage 110 LA DBM Micarta
- Manufacturer: WOOX
- Product no.: EU2018834
- Mfr. No.: SH.CHS013.12
- Colour: Micarta
- Model: 110
- Weapon type: Savage
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393353

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This revolutionary hybrid rifle stock is designed for shooters and hunters who appreciate both classic aesthetics and modern tactical performance. To ensure your safety and the optimal performance of your product, please carefully read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Always handle your firearm and accessories with care and in accordance with local laws and regulations.
- Ensure that your firearm is unloaded when installing or adjusting the chassis.
- Regularly inspect the chassis for any signs of wear or damage, and do not use the product if it appears compromised.
- Keep the product out of reach of children and unauthorized users.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:** The WOOX Furiosa Chassis is designed to enhance accuracy and stability. However, improper use may lead to accidents or injuries.
- **Avoiding Hazards:**
 - Always ensure the firearm is pointed in a safe direction.
 - Do not modify the chassis as it may affect safety and performance.
 - Use only compatible accessories as specified in the product manual.
 - Ensure that all adjustments, such as the length of pull and cheek riser, are securely locked before use.
- **Age Specific Warnings:** This product is not intended for use by individuals under the age of 18 without adult supervision.

Instructions for Installation and Usage

1. Installation:

- Unpack the WOOX Furiosa Chassis and ensure all components are included.
- Follow the manufacturer's instructions for attaching the chassis to your firearm.
- Ensure that the aerospacegrade aluminum core is securely fitted and locked in place.
- Adjust the Length of Pull (LOP) using the pushbutton mechanism to your desired length, between 13.5" and 15" (34.3 cm - 38.1 cm).
- Finetune the microadjustable cheek riser for optimal scope alignment.

2. Usage:

- Always check that the firearm is unloaded before making any adjustments.
- Utilize the MLOK® forend for mounting accessories like bipods or tripods securely.
- Use the integrated Picatinny rail for additional support accessories.
- Ensure that QD sling mounts are properly secured before carrying the firearm.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations for electronic and metal waste.
- Do not dispose of the product in regular household waste.

- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please refer to the contact information provided with your product packaging or visit the official WOOX website.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for prioritizing safety and responsible use.