

Furiosa Chassis CZ 457 DBM Walnut

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm - 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: [WOOX Furiosa Chassis CZ 457 DBM Walnut](#)
- Manufacturer: [WOOX](#)
- Product no.: EU2018835
- Mfr. No.: SH.CHS011.16
- Colour: Walnut
- Model: 457
- Weapon type: CZ
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069394084

Table of Contents

- [Startpage](#)
- [WOOX Furiosa Chassis Safety Instructions](#)
- [About Us](#)

WOOX Furiosa Chassis Safety Instructions

Introduction

Thank you for choosing the WOOX Furiosa Chassis. This innovative rifle stock is designed to provide exceptional performance while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use and maintain your product safely.

General Safety Guidelines

- Ensure that the WOOX Furiosa Chassis is used in accordance with all local laws and regulations regarding firearm usage.
- Always handle firearms with care, treating every firearm as if it is loaded.
- Keep the chassis and all components away from children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage. Do not use if damaged.
- Store the chassis in a secure location when not in use.
- Be aware of your surroundings and ensure you are in a safe environment when handling or using the chassis.

Specific Safety Precautions for Use

- **Proper Handling:** Always keep the muzzle pointed in a safe direction.
- **Shooting Position:** Ensure a stable shooting position when using the chassis to minimize recoil and improve accuracy.
- **Cheek Riser Adjustment:** When adjusting the microadjustable cheek riser, ensure that it is securely locked in place before using the chassis.
- **Length of Pull Adjustment:** Adjust the length of pull (LOP) only when the rifle is not in use. Ensure that the mechanism is fully engaged after adjustment.
- **Accessory Mounting:** When using the MLOK® forend and Picatinny rail, ensure that all accessories are securely mounted to prevent detachment during use.
- **QD Sling Mounts:** Always check that the sling mounts are properly attached before carrying the rifle.

Instructions for Installation and Usage

1. Installation of the Chassis:

- Remove the existing stock from your rifle according to the manufacturer's instructions.
- Align the WOOX Furiosa Chassis with the rifle's action and ensure proper fit.
- Secure the chassis using the included hardware, ensuring all screws are tightened according to the specifications.

2. Adjusting the Cheek Riser:

- Locate the adjustment mechanism on the cheek riser.
- Pull the lever to unlock and adjust the riser to your desired height.
- Release the lever to lock the riser in place.

3. Adjusting the Length of Pull (LOP):

- Locate the pushbutton mechanism on the chassis.
- Press the button and slide the buttstock to your desired length (13.5" to 15").
- Release the button to lock the buttstock in place.

4. Mounting Accessories:

- For MLOK® forend: Slide the accessory into the slot and secure it using the provided screws.
- For Picatinny rail: Slide the accessory onto the rail and tighten the screws until secure.

5. Using QD Sling Mounts:

- Attach your sling to the QD sling mounts by pushing the button on the swivel to engage it into the mount.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis and any components in accordance with local regulations.
- Do not dispose of the chassis in regular household waste. Check for recycling programs in your area.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to your retailer or check the official WOOX website for support resources.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Always prioritize safety and be mindful of your surroundings when using your rifle. Thank you for your attention to these guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk