

Furiosa Chassis CZ 457 DBM Laminated Tiger Wood

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis CZ 457 DBM Laminated Tiger Wood
- Manufacturer: WOOX
- Product no.: EU2018836
- Mfr. No.: SH.CHS012.16
- Colour: Laminated Tiger Wood
- Model: 457
- Weapon type: CZ
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069394091

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instructions](#)

WOOX Furiosa Chassis Safety Instructions

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your shooting and hunting needs. This product is designed to provide a perfect blend of classic aesthetics and modern tactical performance. To ensure your safety and the longevity of your chassis, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the WOOX Furiosa Chassis is used only for its intended purpose.
- Always handle firearms with care and follow all local laws and regulations regarding firearms.
- Keep the chassis and any attached components out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage before each use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Firearm Compatibility:** Ensure that the chassis is compatible with your specific firearm model (CZ 457) before installation.
- **Correct Assembly:** Follow the installation instructions carefully to avoid improper assembly that may lead to malfunctions.
- **Secure Attachments:** Always ensure that any accessories mounted on the MLOK® slots or Picatinny rail are securely fastened.
- **Cheek Riser Adjustment:** Make sure the cheek riser is adjusted correctly to avoid misalignment during shooting.
- **Length of Pull Adjustment:** Adjust the length of pull (LOP) only when the firearm is not loaded and pointed in a safe direction.

Instructions for Installation and Usage

1. Installation of Chassis:

- Remove the existing stock from your CZ 457.
- Align the action of the firearm with the WOOX Furiosa Chassis.
- Secure the action into the chassis using the provided screws, ensuring they are tightened to the manufacturer's specifications.

2. Adjusting Cheek Riser:

- Locate the adjustment mechanism on the cheek riser.
- Pull the lever to release and adjust the riser to your desired height.
- Release the lever to lock the riser in place.

3. Adjusting Length of Pull:

- Locate the pushbutton mechanism on the chassis.
- Press the button and slide the buttstock to the desired LOP (between 13.5" and 15").
- Release the button to secure the adjustment.

4. Mounting Accessories:

- Identify the MLOK® accessory slots on the forend.
- Use compatible MLOK® accessories and follow their specific installation instructions.

- Ensure all accessories are securely attached.

5. Using QD Sling Mounts:

- Attach your sling to the builtin Quick Detach (QD) sling swivel points.
- Ensure the sling is properly secured before use.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis responsibly and in accordance with local regulations.
- Consider recycling components where possible, especially metal parts.
- Do not dispose of the chassis in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety, usage, or technical support, please reach out to your local WOOX distributor or authorized dealer. Ensure you have your product information ready for assistance.

By following these guidelines, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for your commitment to safety.