

Furiosa Chassis Ruger 10/22 10/22 DBM Walnut

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Furiosa Chassis Ruger 10/22 10/22 DBM Walnut
- Manufacturer: WOOX
- Product no.: EU2018838
- Mfr. No.: SH.CHS011.13
- Colour: Walnut
- Model: 10/22
- Weapon type: Ruger
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393360

Table of Contents

- [Startpage](#)
- [English: WOOX Furiosa Chassis Safety Instruction Guide](#)

WOOX Furiosa Chassis Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Ruger 10/22. This guide provides essential safety instructions and guidelines to ensure safe and effective use of your product. Please read this document carefully before installation and use to maximize your safety and performance.

General Safety Guidelines

- Always handle firearms responsibly and with care.
- Ensure that the firearm is unloaded before installing or adjusting the chassis.
- Keep the WOOX Furiosa Chassis out of reach of children and unauthorized users.
- Regularly inspect your chassis for any signs of damage or wear.
- Store the chassis in a safe and secure location when not in use.
- Be aware of your surroundings and ensure that your shooting environment is safe.
- Follow local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- **Hazard Awareness:**
 - Be aware of potential hazards such as accidental discharge, improper installation, and misuse.
- **Installation Precautions:**
 - Only use tools that are appropriate for the installation process.
 - Do not force any components together; ensure that all parts fit correctly.
- **Usage Precautions:**
 - Always wear appropriate eye and ear protection when using firearms.
 - Ensure that the firearm is properly secured in the chassis before firing.
 - Avoid using the chassis in adverse weather conditions that may affect performance.
- **Maintenance Precautions:**
 - Clean the chassis regularly to prevent dirt and debris buildup.
 - Use recommended cleaning products and procedures to maintain the integrity of the materials.

Instructions for Installation and Usage

Installation Steps

1. **Preparation:**
 - Ensure that the firearm is unloaded and the area is clear.
2. **Attach the Chassis:**
 - Align the Ruger 10/22 with the chassis.
 - Securely fasten the chassis to the firearm using the provided hardware.
3. **Adjust Length of Pull (LOP):**
 - Adjust the LOP from 13.5" to 15" by using the pushbutton mechanism.
4. **Install Cheek Riser:**
 - Adjust the cheek riser for optimal scope alignment without additional tools.
5. **Mount Accessories:**
 - Use the MLOK® slots to attach any desired accessories, ensuring they are securely fastened.

Usage Steps

1. **Check Stability:**
 - Ensure that the chassis is stable and that the firearm is securely mounted.
2. **Load the Firearm:**
 - Follow safe loading practices as per your firearm's manual.

3. **Aim and Fire:**

- Aim carefully and ensure that the firing area is clear before shooting.

4. **PostUsage:**

- Unload the firearm and store the chassis in a safe location after use.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis responsibly and in accordance with local regulations.
- Do not dispose of the chassis in regular household waste.
- Check with local authorities for proper disposal methods or recycling options.

Contact Information for Further Support

For any safety inquiries or further support, please reach out to your local WOOX representative or authorized dealer. They can assist you with any questions or concerns regarding your WOOX Furiosa Chassis.

Conclusion

Your safety is paramount when using the WOOX Furiosa Chassis. By following the guidelines and instructions outlined in this document, you can ensure a safe and enjoyable shooting experience. Thank you for your attention to safety, and enjoy your new chassis!