

Furiosa Chassis Ruger 10/22 10/22 DBM Laminated Tiger Wood

[Rifle Parts](#) > [Stock Parts](#) > [Rifle Stocks](#)

The WOOX Furiosa Chassis is a groundbreaking hybrid rifle stock designed for shooters and hunters who refuse to compromise between classic aesthetics and modern tactical performance. Engineered in Italy and crafted in the USA and Italy, the Furiosa combines hand-finished American Walnut (or dark Micarta) with a full-length, rigid aerospace-grade aluminum skeleton. The result is an ultra-stable bedding platform that dramatically enhances shot-to-shot consistency, recoil management,

Aerospace-Grade Aluminum Core: Built on a precision-machined AA 7075 aircraft-grade aluminum sub-chassis with hard anodizing. The metal bedding system eliminates accuracy loss caused by ambient humidity and temperature changes.

Micro-Adjustable Cheek Riser: Fine-tune your cheek weld effortlessly for perfect scope alignment without needing extra tools.

Adjustable Length of Pull (LOP): Rapidly adapt the LOP from 13.5" to 15" (34.3 cm – 38.1 cm) using a smooth push-button mechanism.

M-LOK® Forend: Three 7-inch M-LOK® accessory slots (at 3, 6, and 9 o'clock) for mounting bipods, tripods, or lights.

Integrated Picatinny Rail: Bottom-mounted rail section for monopods and rear support accessories.

QD Sling Mounts: Built-in Quick Detach sling swivel points for flexible carry options.

NO IMAGE
AVAILABLE

Attributes

- Name: [WOOX Furiosa Chassis Ruger 10/22 10/22 DBM Laminated Tiger Wood](#)
- Manufacturer: [WOOX](#)
- Product no.: EU2018839
- Mfr. No.: SH.CHS012.13
- Colour: Laminated Tiger Wood
- Model: 10/22
- Weapon type: Ruger
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069393377

Table of Contents

- [Startpage](#)
- [WOOX Furiosa Chassis Safety Instructions](#)
- [About Us](#)

WOOX Furiosa Chassis Safety Instructions

Introduction

Thank you for choosing the WOOX Furiosa Chassis for your Ruger 10/22. This product has been designed with safety and performance in mind. Please read this safety instruction guide carefully to ensure safe and effective use of your chassis.

General Safety Guidelines

- Always handle firearms with care and assume they are loaded until verified otherwise.
- Ensure that the WOOX Furiosa Chassis is properly installed and securely attached to your firearm before use.
- Keep the chassis and firearm out of reach of children and unauthorized users.
- Regularly inspect the chassis for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm use and storage.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about recall updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- **Firearm Compatibility:** Ensure the chassis is specifically designed for the Ruger 10/22 model.
- **Proper Use:** Do not use the chassis for any purpose other than its intended use as a rifle stock.
- **Weight Limitations:** Be aware of the weight of your firearm and any attachments to avoid compromising stability and safety.
- **Environmental Conditions:** Avoid using the chassis in extreme weather conditions that may affect performance.
- **Check for Obstructions:** Before firing, ensure that there are no obstructions in the barrel or around the chassis.

Instructions for Installation and Usage

Installation

1. **Unpack the Chassis:** Carefully remove the WOOX Furiosa Chassis from its packaging.
2. **Inspect the Chassis:** Check for any visible damage or defects before installation.
3. **Attach to Firearm:**
 - Align the chassis with the Ruger 10/22 receiver.
 - Securely fasten all screws and components according to the manufacturer's specifications.
4. **Verify Stability:** Ensure that the chassis is firmly attached and stable before proceeding to use the firearm.

Usage

- **Adjusting Length of Pull (LOP):**
 - Use the pushbutton mechanism to adjust the LOP from 13.5" to 15".
 - Ensure the adjustment is secure before using the firearm.
- **MicroAdjustable Cheek Riser:**
 - Adjust the cheek riser for optimal scope alignment.
 - Confirm that the riser is locked in place before shooting.
- **Mounting Accessories:**
 - Utilize the MLOK® slots for attaching bipods, tripods, or other accessories.
 - Ensure all accessories are securely mounted and do not obstruct the operation of the firearm.

Disposal Instructions

- Dispose of the WOOX Furiosa Chassis in accordance with local regulations regarding electronic and plastic waste.
- Do not discard the chassis in regular household waste.
- Check with local authorities or recycling centers for appropriate disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the WOOX Furiosa Chassis, please refer to the manufacturer's website or contact your local dealer for assistance. Ensure you have your product details ready for efficient support.

By following these safety instructions, you can ensure a safe and enjoyable experience with your WOOX Furiosa Chassis. Thank you for prioritizing safety and responsible firearm use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk