

Forty-Seven - EDGE Stock AK-47 Fixed Walnut/Aluminum

Skeletonized Design: Hard-anodized aerospace-grade aluminum skeleton frame that keeps overall weight low while maintaining high structural rigidity. Folding Mechanism: Features an integrated hinge system that folds to the side for compact transport or storage. Walnut Touchpoints: Cheek Riser: Genuine American Walnut cheekpiece, height-adjustable for optic alignment. Buttplate Accent: Walnut insert backed by a shock-absorbing Microcell recoil pad. Sling Attachment: Dual-sided Quick Detach (QD) sockets for ambidextrous sling setups.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Forty-Seven - EDGE Stock AK-47 Fixed Walnut/Aluminum
- Manufacturer: WOOX
- Product no.: EU2019174
- Mfr. No.: SH.STK122.03
- Colour: Walnut
- Model: AK-47
- Weapon type: AK-47
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069397511

Table of Contents

- [Startpage](#)
- [English: WOOX FortySeven EDGE Stock AK47 Fixed Walnut/Aluminum Safety Instruction Guide](#)

WOOX FortySeven EDGE Stock AK47 Fixed Walnut/Aluminum Safety Instruction Guide

Introduction

Thank you for choosing the WOOX FortySeven EDGE Stock AK47 Fixed Walnut/Aluminum. This guide provides essential safety instructions to ensure the safe use and handling of your product. Please read this document carefully to understand how to use the product safely and responsibly.

General Safety Guidelines

- Ensure that all users are familiar with the product and its features before use.
- Regularly inspect the product for any signs of wear or damage.
- Store the product in a safe, dry place when not in use.
- Keep the product out of reach of children and unauthorized users.
- Always follow local laws and regulations regarding the use of firearms and firearm accessories.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

• Hazard Identification:

- Improper use may lead to accidental discharge or injury.
- Ensure that the product is securely attached to the firearm before use.
- Be aware of your surroundings and ensure the area is safe before handling the product.

• Avoiding Hazards:

- Always treat the firearm as if it is loaded.
- Do not point the firearm at anything you do not intend to shoot.
- Use only the recommended accessories and components with this product.
- Do not modify the product in any way that could compromise its safety.

• AgeSpecific Warnings:

- This product is intended for use by adults only. Keep away from children and unauthorized users.

Instructions for Installation and Usage

• Installation:

1. Ensure that the firearm is unloaded and pointed in a safe direction.
2. Attach the WOOX FortySeven stock to the firearm according to the manufacturer's instructions.
3. Secure all screws and fasteners to ensure stability.
4. Adjust the cheek riser to the desired height for optimal optic alignment.

• Usage:

- Before each use, perform a safety check to ensure that the stock is securely attached.
- Use the dualsided Quick Detach (QD) sockets for ambidextrous sling setups as needed.
- Maintain a proper shooting stance and ensure that your grip is secure.

Disposal Instructions

- Dispose of the product in accordance with local regulations for waste disposal.
- If the product is damaged or no longer in use, consider recycling components where possible.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the WOOX FortySeven EDGE Stock AK47 Fixed Walnut/Aluminum, please refer to the manufacturer's website or contact your local distributor for assistance. Ensure that you have the product details available for efficient support.

Thank you for your attention to these safety guidelines. Enjoy your WOOX FortySeven stock responsibly!