

Rifle Accessories - WOOX 1-Way Vertical Adj. Recoil Pad Rifle accessory 1-Way Vertical Adjustment

Function: Adds vertical position adjustment to the recoil pad, allowing shooters to raise or lower the pad relative to the stock axis for ideal shoulder pocket placement and cheek weld alignment.

Recoil Management: Built with high-density, shock-absorbing material to cushion impact, reduce felt recoil, and help maintain sight picture during rapid follow-up shots.

Adjustability: Features an integrated vertical sliding mechanism that locks securely at the desired height setting to accommodate different shooting positions (prone, bench, or standing) and body builds.

Compatibility: Engineered specifically for WOOX modular stock and chassis systems equipped with adjustable buttplate interfaces.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX 1-Way Vertical Adj. Recoil Pad Rifle accessory 1-Way Vertical Adjustment
- Manufacturer: WOOX
- Product no.: EU2019235
- Mfr. No.: SH.RCP002.01
- Colour: Black
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069391595

Table of Contents

- [Startpage](#)
- [English: WOOX Rifle Accessories Safety Instruction Guide](#)

WOOX Rifle Accessories Safety Instruction Guide

Introduction

Thank you for choosing the WOOX 1Way Vertical Adjustable Recoil Pad. This product is designed to enhance your shooting experience by providing adjustable comfort and improved recoil management. To ensure safe and effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the recoil pad is compatible with your WOOX modular stock and chassis system.
- Always handle firearms safely and responsibly, following all local laws and regulations.
- Keep the recoil pad and all accessories out of reach of children and unauthorized users.
- Regularly inspect the recoil pad for wear and damage before each use.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before making any adjustments to the recoil pad.
- Adjust the recoil pad only when the firearm is in a safe position, pointed in a safe direction.
- Do not exceed the recommended height adjustment for the recoil pad to avoid instability during use.
- Ensure that the locking mechanism is secure after adjusting the height to prevent accidental movement.
- Use appropriate eye and ear protection while shooting.

Instructions for Installation and Usage

1. Installation of the Recoil Pad:

- Remove the existing recoil pad from your WOOX stock if applicable.
- Align the WOOX 1Way Vertical Adjustable Recoil Pad with the mounting points on the stock.
- Securely fasten the recoil pad using the provided screws, ensuring it is tightly fitted.
- Confirm that the pad is stable and does not move when pulled or pushed.

2. Adjusting the Recoil Pad:

- To adjust the height, locate the integrated vertical sliding mechanism.
- Pull the mechanism to unlock it, then slide the recoil pad to the desired height.
- Release the mechanism to lock it securely in place.
- Test the adjustment by applying gentle pressure to ensure it is locked in position.

3. Using the Recoil Pad:

- Position the rifle against your shoulder, ensuring that the recoil pad is aligned with your shoulder pocket.
- Maintain a firm grip on the rifle and prepare for shooting.
- After firing, assess the comfort and effectiveness of the recoil pad, making further adjustments if necessary.

Disposal Instructions

- Dispose of the recoil pad in accordance with local regulations.
- If the recoil pad is damaged beyond repair, consider recycling the materials if possible.
- Do not dispose of the recoil pad in household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the WOOX 1Way Vertical Adjustable Recoil Pad, please refer to the official WOOX website or your local retailer for assistance.

Thank you for choosing WOOX. Enjoy your shooting experience safely!