

## Rifle Accessories - WOOX WOOX Bag Rider Rifle accessory Midnight grey

Function: Attaches to the bottom rear of the stock to provide a smooth, flat surface for riding on a rear shooting bag, facilitating subtle elevation adjustments and smoother tracking during recoil.

Construction and Finish: CNC-machined from high-grade aircraft aluminum for maximum rigidity, finished with a durable, weather-resistant coating that glides easily against bag material.

Design and Fit: Engineered with an angled/sloped profile that allows micro-adjustments in target alignment simply by sliding the rear bag forward or backward.

Compatibility: Designed specifically for WOOX precision chassis systems, such as the Furiosa and Furiosa Ultra stock setups.

NO IMAGE  
AVAILABLE

### Attributes

- Name: WOOX WOOX Bag Rider Rifle accessory Midnight grey
- Manufacturer: WOOX
- Product no.: EU2019247
- Mfr. No.: SH.BGR001.01
- Colour: Midnight Grey
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069391434

# Table of Contents

- [Startpage](#)
- [English: WOOX Bag Rider Rifle Accessory Safety Instruction Guide](#)

# WOOX Bag Rider Rifle Accessory Safety Instruction Guide

## Introduction

Thank you for choosing the WOOX Bag Rider Rifle Accessory. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read this manual carefully before using the Bag Rider to familiarize yourself with its features and safety precautions.

## General Safety Guidelines

- Ensure that the Bag Rider is compatible with your WOOX precision chassis systems, such as the Furiosa and Furiosa Ultra stock setups.
- Always follow local laws and regulations regarding the use of firearms and accessories.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the Bag Rider for wear or damage before each use. Do not use if damaged.
- Store the Bag Rider in a cool, dry place when not in use to prevent deterioration.

## Specific Safety Precautions for Use

- Use the Bag Rider only for its intended purpose: to provide a stable rear support for shooting.
- Avoid using the Bag Rider on unstable or uneven surfaces to prevent accidents.
- Do not exceed the manufacturer's weight limit for the Bag Rider; refer to the product specifications for details.
- When making adjustments, ensure that your firearm is pointed in a safe direction at all times.
- Always wear appropriate eye and ear protection when using firearms.

## Instructions for Installation and Usage

### Installation

#### 1. Prepare the Rifle:

- Ensure the rifle is unloaded and pointed in a safe direction.
- Remove any existing accessories from the stock if necessary.

#### 2. Attach the Bag Rider:

- Align the Bag Rider with the bottom rear of the stock.
- Securely attach the Bag Rider using the provided screws and tools.
- Ensure that the Bag Rider is firmly attached and does not move.

#### 3. Check Alignment:

- Verify that the Bag Rider is properly aligned for optimal use.
- Make any necessary adjustments to ensure a smooth fit.

### Usage

#### 1. Setting Up:

- Place the rifle on a stable shooting surface.
- Position the rear shooting bag under the Bag Rider.

## **2. Adjusting for Elevation:**

- To make microadjustments in target alignment, slide the rear bag forward or backward as needed.
- Ensure the rifle remains stable during adjustments.

## **3. During Use:**

- Maintain a firm grip on the rifle while shooting.
- Monitor the Bag Rider for any signs of wear or instability during use.

## **Disposal Instructions**

- Dispose of the Bag Rider in accordance with local regulations for metal and plastic waste.
- Do not dispose of the product in regular household waste.
- Consider recycling options for the materials used in the Bag Rider.

## **Contact Information for Further Support**

For any inquiries regarding safety, product issues, or to report unsafe products, please contact your local WOOX representative or visit the official WOOX website for assistance.

Thank you for your attention to these safety guidelines. Your safety is our priority, and we hope you enjoy using the WOOX Bag Rider Rifle Accessory responsibly.