

Blades Accessories - WOOX AX1 Standard Black Sheath Axe accessory Sheath / Axe AX1 Axe Leather

Material: Premium black leather built to protect the sharp edge during storage and transport.

Design and Fit: Custom-molded to fit securely over the head of the AX1 hatchet.

Secure Retention: Features reliable snap closures and heavy-duty riveting to keep the sheath firmly locked in place over the blade.

Safety and Protection: Prevents accidental cuts and guards the cutting edge against moisture, dings, and dulling elements in your pack or camp gear.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX AX1 Standard Black Sheath Axe accessory Sheath / Axe AX1 Axe Leather
- Manufacturer: WOOX
- Product no.: EU2019290
- Mfr. No.: BU.SHT002.02
- Colour: Black
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069392967

Table of Contents

- [Startpage](#)
- [English: WOOX AX1 Standard Black Sheath Safety Instructions](#)

WOOX AX1 Standard Black Sheath Safety Instructions

Introduction

Thank you for choosing the WOOX AX1 Standard Black Sheath. This product is designed to protect your AX1 hatchet's sharp edge during storage and transport. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always inspect the sheath for any signs of damage before use.
- Ensure the sheath is securely fastened over the hatchet head before transporting.
- Keep the sheath stored in a dry place to prevent moisture damage.
- Do not use the sheath for purposes other than protecting the AX1 hatchet.
- Keep the sheath out of reach of children to prevent accidental injury.

Specific Safety Precautions for Use

- **Avoid Contact with Water:** The sheath is not waterproof. Prolonged exposure to moisture can damage the leather and compromise protection.
- **Secure Closure:** Always check that the snap closures are properly engaged before moving or storing the hatchet.
- **Regular Maintenance:** Clean the leather sheath periodically with a dry cloth to maintain its condition and longevity.
- **Avoid Sharp Objects:** Do not place sharp objects inside the sheath, as this may cause damage or compromise safety.
- **Child Safety:** This product is not intended for use by children. Always supervise children around sharp tools.

Instructions for Installation and Usage

1. **Fitting the Sheath:**
 - Align the sheath with the head of the AX1 hatchet.
 - Gently slide the sheath over the hatchet head until it fits snugly.
2. **Securing the Sheath:**
 - Ensure that the sheath covers the blade completely.
 - Engage the snap closures to secure the sheath in place.
3. **Transporting the Hatchet:**
 - Always carry the hatchet with the sheath attached.
 - Store the hatchet in a dry, cool place when not in use.
4. **Removing the Sheath:**
 - To remove the sheath, gently pull it away from the hatchet head.
 - Avoid using excessive force to prevent damage to the sheath or hatchet.

Disposal Instructions

- Dispose of the sheath responsibly according to local waste management guidelines.
- Leather products can often be recycled. Check with local recycling facilities for options.
- If the sheath is damaged beyond use, ensure it is disposed of in a way that prevents accidental injury.

Contact Information for Further Support

For any inquiries related to safety or product issues, please reach out to the designated EU contact point provided with your product packaging or visit the manufacturer's website for more information.

Conclusion

Following these safety instructions will help ensure the safe use of your WOOX AX1 Standard Black Sheath. Always prioritize safety and maintenance to enjoy the best experience with your product. Thank you for choosing WOOX.